

Marke	ID-Nummer	Code
888	0006	0692, 0405, 0417
A.R. Systems	0012	0037, 0556, 0138, 0356, 0346, 0797, 0272
Accent	0019	0037, 0395
ACE	0026	0830
Acer	0028	1339, 0173, 0247, 0351
Acme	3521	0061, 0126
Acoustech	5094	1531
Acoustic Solutions	0032	1037, 1523, 1667, 0469, 1865
Action	0033	0650
Acura	0036	0699, 0386, 0060, 0395
ADA	0038	0699, 0697
ADC	0040	0692, 0693
Addison	0043	0108, 0653, 0399
ADL	0045	1217
Admiral	0046	0463, 0012, 0692, 0056, 0648, 0090, 0071, 0658, 0072, 0224, 0691, 0754, 0755, 0398, 0405
Advent	0054	1613
Adyson	0058	0061, 0328, 0330, 0787, 0788, 0794, 0802, 0347, 0404, 0364
AEG	0059	1037, 1163, 1556, 1324, 0250, 0252, 0254, 0268, 0285, 0286, 0289, 0321, 0334, 0354
Aftron	3470	0891
Agashi	0063	0658, 0328, 0330, 0787, 0788, 0347, 0794, 0405
Agazi	3522	0692
AGB	0064	0790
Agfaphoto	4766	0322
Aiko	0069	0037, 1681, 0061, 0699, 0138, 0328, 0060, 0330, 0207, 0386, 0124, 0660, 0693, 0347, 0787, 0788, 0346, 0293, 0404, 0392, 0794, 0395, 0453, 0405
Aim	0070	0037, 0706, 0753, 0138, 0346, 0357, 0798, 0417, 0425
Airis	0071	1531, 1833, 2050
Aiwa	0072	0042, 0216, 0140, 0238, 0460, 0434, 1916
Akai	0074	0037, 0178, 0208, 0556, 0702, 0020, 0753, 0812, 1675, 2232, 0699, 0138, 0086, 0064, 0293, 0102, 0107, 0207, 0328, 0658, 0330, 0060, 0122, 0790, 0112, 0647, 0124, 0730, 0386, 0664, 0660, 0693, 0347, 0349, 0346, 0663, 0361, 0357, 0758, 0787, 0788, 0760, 0359, 0365, 0404, 0367, 0697, 0392, 0406, 0794, 0798, 0801, 0800, 1118, 0395, 1326, 0439, 0417, 0437, 0548, 0480, 0405, 0421, 1308, 1865, 0055, 0290, 0292
Akashi	0075	0860, 0395
Akiba	0078	0037, 0064, 0138, 0346, 0349, 0151, 0357, 0411, 0406, 0124, 0367, 0236, 0798, 0663, 0427
Akira	0079	0753, 1733
Akito	0082	0037, 0138, 0710, 0346, 0357, 0798, 0279
Akura	0083	0037, 0171, 0668, 0020, 1037, 1363, 1556, 1667, 0692, 0138, 0064, 0124, 0346, 0060, 0349, 0151, 0386, 0357, 0359, 0367, 0411, 0406, 0663, 0798, 0800, 0405, 0469, 1770, 0417, 0395, 1982, 1983
Alaron	0085	0328, 0787, 0347, 0794
Alba	0086	0037, 0668, 0020, 1037, 2104, 0138, 0061, 0699, 0060, 0741, 0064, 0124, 0713, 0224, 0328, 0112, 0207, 0197, 0127, 0162, 0179, 0386, 0347, 0349, 0326, 0217, 0361, 0666, 0346, 0795, 0364, 0357, 0787, 0359, 0406, 0661, 0367, 0663, 0802, 0801, 0794, 0798, 0800, 1054, 0395, 0418, 2050
ALBIRAL	3775	0033
Alcyon	0093	0044, 0750
Alkos	3523	0761, 0110
Allorgan	0105	0330, 0165, 0404, 0788, 0711, 0413
Allstar	0108	0037, 0086, 0138, 0730, 0346, 0357, 0798, 0367
Amitech	0130	0430
Amoi	0132	0253, 0768
Amplivision	0138	0741, 0061, 0330, 0218, 0788, 0404, 0416
Amstrad	0140	0037, 0171, 1037, 0692, 0138, 0699, 0060, 0064, 0222, 0200, 0790, 0106, 0207, 0658, 0386, 0346, 0349, 0287, 0361, 0357, 0367, 0663, 0406, 0124, 0798, 0801, 0395, 0405, 0417, 1324, 1982
AmTRAN	3785	2127
Anam	0146	0037, 0699, 0119, 0091, 0395
Anam National	0147	0037, 0650, 0138, 0346
Andersson	0148	1163, 1585
Anglo	0151	0699, 0386, 0060, 0395, 0405
Anhua	0153	0833
Anitech	0154	0037, 0044, 0692, 0060, 0083, 0699, 0138, 0089, 0658, 0386, 0346, 0357, 0367, 0725, 0750, 0798, 0395, 0405, 0285, 0286, 0289, 0321, 0334, 0354

Ansonic	0156	0037, 0668, 0138, 0741, 0699, 0060, 0751, 0386, 0666, 0703, 0346, 0367, 0390, 0667, 0409, 0426, 0395
ANTECNO	4601	0124
AOC	0165	0108, 0178, 0625, 1365, 1589, 1169, 0395, 2111, 0398, 0399, 0009
Aolinpike	0168	0405, 0417
Aolinpiya	4089	0692
Aolinpu	4090	0814
Apex Digital	0170	0156, 1217
Apollo	0171	0847, 0429, 0421
Arc En Ciel	0178	0726, 0104, 0759, 0400
Arcam	0179	0328, 0330, 0787, 0788, 0802, 0347, 0404, 0364
Arcam Delta	3524	0061
Ardem	0184	0037, 0020, 0798, 0357, 0800, 0359, 0486
Arena	3375	0037
Aristona	0192	0037, 0556, 0086, 0138, 0730, 0112, 0346, 0390, 0357, 0798, 0367
ART	0199	1037
Art Mito	3737	1585
Arthur Martin	0200	0218
ASA	0202	0090, 0705, 0056, 0648, 0396, 0096, 0166, 0072, 0704, 0691, 0707, 0755
Asberg	0205	0037, 0044, 0086, 0089, 0138, 0730, 0725, 0346, 0357, 0750, 0798
Asora	0213	0395
Astar	0218	1531
Astra	0221	0037, 0699, 0658
Asuka	0227	0692, 0124, 0061, 0151, 0328, 0330, 0064, 0663, 0347, 0787, 0788, 0349, 0404, 0406, 0411, 0405
ATD	0229	0698
Atec	0230	1606
Atlantic	0233	0037, 0061, 0086, 0138, 0117, 0730, 0328, 0112, 0651, 0787, 0347, 0346, 0794, 0416, 0357, 0798, 0409
Atori	0237	0699, 0386, 0060, 0395
Atoro	4518	0658
Auchan	0240	0218
Audiosonic	0264	0037, 0020, 0820, 1681, 2104, 0138, 0061, 0699, 0741, 0086, 0658, 0124, 0064, 0730, 0104, 0330, 0663, 0112, 0356, 0188, 0797, 0349, 0788, 0346, 0759, 0357, 0359, 0404, 0798, 0367, 0406, 0800, 0395, 0400, 1308, 2050, 0437, 0405, 0486, 1983
Audioton	0266	0741, 0658, 0061, 0330, 0788, 0404, 0486, 0405
Audiovox	0268	0335
Audioworld	0269	0698
Ausind	0276	0655, 0044, 0725, 0671, 0750
Autovox	0280	0089, 0090, 0692, 0056, 0061, 0330, 0044, 0117, 0166, 0666, 0845, 0404, 0691, 0671, 0419, 0725, 0750, 0788
Aventura	0287	0171
Awa	0296	0108, 1681, 0138, 0328, 0658, 0330, 0170, 0647, 0787, 0788, 0344, 0388, 0347, 0796, 0792, 0794, 0395, 0417, 0399, 0405
Axxent	0302	0395
Axxon	0303	0020
Ayomi	3525	0404, 0844
B&D	3609	1217
Baier	0308	1324
Baihe	0309	0395, 0405, 0417
Baihehua	4091	0839
Baihua	4092	0805, 0692
Baile	0310	0805, 0837, 0395
Baird	0311	0208, 0104, 0330, 0293, 0647, 0365, 0788, 0759, 0404, 0407, 0400
Bang & Olufsen	0314	0565, 0090, 0056, 0340, 0691, 0428
Baohuashi	0316	0692, 0405, 0417
Baosheng	0318	0805, 0835, 0395
Barco	0319	0556, 0031, 0033
BARON	3959	0811
Base	0322	0445
Basic Line	0325	0037, 0556, 0668, 1037, 1163, 0699, 0138, 0086, 0060, 0064, 0124, 0330, 0151, 0346, 0730, 0386, 0356, 0349, 0357, 0367, 0797, 0663, 0788, 0411, 0406, 0798, 0395
Bastide	0327	0061, 0330, 0788, 0404
Bauer	0329	0658, 0395, 0405
Baur	0331	0037, 0195, 0512, 0107, 0138, 0112, 0000, 0248, 0357, 0367, 0419, 0760, 0845, 0346, 0244, 0257, 0027, 0798, 0697, 0395
Baysonic	0333	0463
Bazin	0335	0330, 0788, 0404

Beaumarck	0340	0178
Beijing	0345	0208, 0226, 0812, 0821, 0122, 0376, 0699, 0805, 0372, 0804, 0835, 0692, 0837, 0839, 0395, 0402, 0405, 0417
Beko	0346	0037, 1652, 0020, 0741, 0138, 0511, 0412, 0346, 0795, 0359, 0367, 0696, 0800, 0486, 0437, 0450
Belson	0355	0698, 2032
Belstar	0357	1037
BenQ	0359	1562, 0237, 0763
Bensten	3559	1326
Beon	0361	0037, 0138, 0112, 0730, 0346, 0224, 0357, 0367, 0798, 0795
Berthen	0363	0668
Best	0364	0138, 0741, 0346, 0188
Bestar	0368	0037, 0138, 0086, 0741, 0730, 0346, 0356, 0797, 0352, 0357, 0798, 0367
Bestar-Daewoo	0369	0797, 0356
Bestavision	0370	0854
Bestwell	3560	1326
Bigston	4519	0658
Binatone	0378	0061, 0330, 0788, 0404
Black Diamond	0384	0753, 0820, 0821, 1037, 1163, 0614
Black Star	0386	0099, 0666
Blacktron	3526	0411, 0151
Blackway	0388	0411, 0151
Blaupunkt	0390	0195, 0027, 0697, 0137, 0116, 0175, 0257
Blue Media	3378	1606
Blue Sky	0395	0037, 0556, 0625, 0668, 0020, 1037, 1314, 1363, 1652, 0064, 0138, 0124, 0349, 0346, 0151, 0357, 0411, 0406, 0236, 0367, 0359, 0798, 0663, 0800, 0427, 1324, 1709, 0437, 1909, 0450, 1916
Blue Star	0396	0095, 0151, 0411, 0757
Boca	0399	1652
Boman	0402	1324
Bondstec	0403	0099, 0666
Boots	0405	0061, 0710, 0330, 0788, 0404, 0395
Bork	3615	1363
BPL	0413	0037, 0208, 0896, 1476, 1543, 0095, 0138, 0170, 0151, 0346, 0411, 0798, 0367, 0357, 0757, 1208
Brandt	0416	0560, 0625, 0020, 0414, 0726, 0104, 0467, 0185, 0138, 0187, 0352, 0153, 0727, 0759, 0400, 0407
Brilliant	0422	1255
Brimax	3797	1709
Brinkmann	0423	0037, 0668, 0138, 0346, 0795, 0357, 0367, 0798, 0224, 0486
Briovega	0424	0037, 0056, 0086, 0648, 0090, 0138, 0112, 0346, 0730, 0691, 0651
Britannia	0425	0061, 0328, 0330, 0787, 0788, 0794, 0802, 0347, 0404, 0364
Broksonic	0432	0463
Brother	0433	0405
Bruns	0435	0090, 0056, 0648, 0281, 0649, 0691, 0696, 0486
BskyB	0436	0382, 0012, 0000, 0023, 0074, 0126, 0180, 0234, 0468, 0471, 0856, 0277, 0865, 0868, 0838, 0870, 0871, 0872, 0873, 0874, 0875, 0876, 0877, 0878, 0883, 0884, 0886, 0887, 0888
BSR	0437	0101, 0165, 0711, 0413
BTC	0439	0064, 0124, 0349, 0663, 0406
Bush	0445	0037, 0208, 0556, 0668, 0698, 0020, 1037, 1556, 1523, 1652, 1667, 2104, 0699, 0064, 0071, 0060, 0086, 0138, 0710, 0124, 0713, 0104, 0101, 0095, 0127, 0151, 0213, 0162, 0330, 0140, 0165, 0356, 0207, 0112, 0386, 0113, 0179, 0180, 0238, 0197, 0709, 0170, 0201, 0349, 0326, 0730, 0361, 0404, 0279, 0419, 0346, 0465, 0357, 0359, 0845, 0754, 0367, 0797, 0661, 0411, 0788, 0406, 0413, 0663, 0757, 0759, 0778, 0786, 0798, 0800, 0801, 0858, 0395, 1326, 0614, 2127, 0432, 0405, 0469, 1982, 1916, 1682, 1308, 2053, 2050, 1983
Cabletime	0457	0825
Caihong	0462	0376, 0805, 0804, 0835, 0395
Cailing	0463	0860
Caishi	0465	0891
Caixing	4093	0839
Cameron	4032	1523, 0383, 0879, 0880, 0764
Camper	3911	0037, 0486
Canal Digital	0476	1253, 1393, 1423, 1523, 1540, 1601, 1825, 2182, 2429, 1173
Capsonic	0486	0692, 0405
Carad	0488	0668, 1037, 0138, 0346, 0610
Carena	0489	0037, 0138, 0346, 0357, 0367, 0798, 0236, 0427
Carrefour	0492	0037, 0138, 0713, 0367, 0396, 0661
Cascade	0496	0037, 0699, 0138, 0060, 0346, 0386, 0357, 0367, 0798, 0395
Casio	0499	0037, 0138, 0766, 0346, 0357, 0798

Cat	0500	1682
Catha	4094	0138, 0346
Cathay	0501	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357, 0367
Caton	4095	0124
CCE	0504	0037, 0330, 0138, 0788, 0346, 0798, 0357, 0367
Celebrity	0509	0000
Celestial	0511	0820, 0821
cello	0514	1770
Centrex	0516	0891, 0445, 1536
Centrum	0519	1037
Centurion	0520	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357, 0367
Century	0521	0090, 0648, 0056, 0666, 0691
CGE	0523	0033, 0089, 0741, 0099, 0044, 0658, 0224, 0101, 0725, 0666, 0795, 0750, 0397
CGM	3449	0124, 0658
Champion	0525	0699, 0835
Changcheng	0526	0376, 0699, 0805, 0833, 0804, 0835, 0837, 0839, 0692, 0395, 0405, 0417
Changfei	0527	0376, 0805, 0804, 0835, 0841, 0395
Changfeng	0528	0753, 0804, 0835, 0692, 0405, 0417
Changhai	0529	0376, 0805, 0804, 0835, 0841, 0395
Changhong	0530	0156, 0508, 0820, 0821, 0122, 0374, 0376, 0805, 0460, 0372, 0804, 0395, 0405
Chaparral	0533	0823
Chengdu	0535	0804, 0835, 0395
Chimei	3563	0245, 0320, 1852, 1217, 1666
Ching Tai	0541	0395
Chuangjia	4096	0377, 0860
Chun Yun	0545	0000, 0706, 1756, 0395
Chunfeng	0546	0805, 0692, 0376, 0395, 0405
Chung Hsin	0547	0108, 0399
Chungfeng	0548	0417
Chunlan	4097	0842
Chunsun	0549	0376, 0805, 0804, 0835, 0395
CIE	4520	0124
Cimline	0552	0699, 0060, 0386, 0349, 0127, 0406, 0663, 0395
Cinex	0563	1556
City	0569	0699, 0386, 0060, 0395
Clarivox	0576	0037, 0138, 0648, 0112, 0657, 0357, 0671, 0367, 0798
Clatronic	0581	0037, 0020, 0138, 0044, 0692, 0089, 0061, 0699, 0086, 0099, 0741, 0060, 0207, 0200, 0064, 0330, 0124, 0730, 0663, 0666, 0667, 0386, 0346, 0349, 0725, 0352, 0357, 0361, 0750, 0788, 0359, 0404, 0367, 0798, 0416, 0406, 0801, 0800, 0405, 0395, 1324
Clayton	0582	1037
CMS	0590	0328, 0787
CMS Hightec	0591	0330, 0788
Coby	0597	2306, 2348, 1176
Commercial Solutions	0615	1447
Concorde	0626	0699, 0386, 0060, 0395
Condor	0627	0037, 0138, 0061, 0086, 0741, 0658, 0328, 0060, 0151, 0730, 0346, 0347, 0386, 0666, 0795, 0357, 0787, 0367, 0667, 0794, 0411, 0416, 0798, 0426, 0395, 0405
Conia	0628	0820, 0821, 1523, 0444, 2032
Conrac	0632	0450
Conrowa	0634	0156, 0698, 0753, 0803, 0805, 0692, 0369, 0395, 0405, 0417
Contec	0635	0037, 0060, 0699, 0061, 0658, 0713, 0200, 0328, 0386, 0661, 0347, 0357, 0364, 0787, 0388, 0716, 0794, 0798, 0802, 0395, 0405
Continental Edison	0637	0185, 0726, 0153, 0104, 0727, 0759, 0400
Cosmel	0647	0037, 0699, 0138, 0658, 0386, 0357, 0060, 0367, 0188, 0798, 0395
Crosley	0655	0000, 0089, 0090, 0648, 0099, 0056, 0044, 0666, 0691, 0101, 0725, 0750, 0397
Crown	0658	0037, 0208, 0668, 0712, 0020, 1037, 1652, 0138, 0060, 0699, 0086, 0044, 0089, 0741, 0210, 0224, 0658, 0112, 0730, 0386, 0124, 0346, 0725, 0357, 0795, 0367, 0750, 0359, 0798, 0800, 0395, 0486, 0437
CS Electronics	0663	0061, 0124, 0099, 0064, 0328, 0666, 0663, 0787, 0347, 0349, 0802, 0794, 0364, 0406
CTC	0664	0099, 0703
CTC Clatronic	3527	0124, 0658, 0703
C-Tech	0449	0891, 0896
CTX	0665	1756
Curtis	0666	2352
Curtis Mathes	0667	0702, 1661, 0398

CWN	0668	0430
CWR-Tech	4778	1324
Cybertron	0675	0064, 0124, 0349, 0663, 0406
Cytronix	0681	1298
Daewoo	0692	0037, 0108, 0178, 0556, 0634, 0860, 1661, 2098, 0036, 0138, 0699, 0086, 0061, 0060, 0047, 0213, 0136, 0219, 0225, 0658, 0466, 0730, 0771, 0325, 0124, 0328, 0386, 0330, 0346, 0347, 0349, 0356, 0733, 0797, 0663, 0352, 0357, 0787, 0788, 0367, 0775, 0404, 0406, 0794, 0798, 1081, 0425, 1909, 0395, 0459, 0453, 0399, 0030, 0301
Dainichi	0694	0064, 0328, 0124, 0663, 0787, 0347, 0349, 0802, 0364, 0406, 0794
Dansai	0699	0037, 0208, 0692, 0086, 0138, 0660, 0730, 0328, 0330, 0112, 0787, 0788, 0346, 0347, 0794, 0364, 0802, 0357, 0798, 0367, 0392, 0405, 0395
Dansette	0701	0417
Dantax	0702	0020, 1037, 1163, 1652, 0138, 0741, 0092, 0112, 0113, 0800, 0359, 0486, 1916, 0437
Datong	4991	0345, 0360
Datron	4201	0037
Datsura	0703	0208, 0210
Dawa	0707	0037, 0138, 0346, 0357, 0798, 0395
Daytek	0708	0405
Dayton	0709	0395
Daytron	0710	0699, 0138, 0060, 0346, 0386, 0356, 0357, 0797, 0798, 0395
Dayu	0711	0837
De Graaf	0716	0208, 0071, 0122, 0754, 0719, 0548
DEC	0717	0860, 0891, 1326
Decca	0718	0037, 0061, 0138, 0293, 0086, 0200, 0134, 0710, 0330, 0112, 0170, 0790, 0730, 0279, 0693, 0647, 0346, 0357, 0788, 0365, 0367, 0404, 0798, 0459
Deitron	0722	0138, 0346
Denko	0730	0405
Denver	0733	0037, 0138, 0233, 0326, 0658, 0357, 0367, 0302, 0798, 1324, 2050, 1709, 0077, 0269, 0303, 0307, 0350, 0353, 0373, 0375
Desmet	0738	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0416, 0357, 0367, 0395
Diamant	0746	0037, 0138, 0346, 0357, 0798, 0367
Diamond	0747	0698, 0706, 0820, 0860, 0896, 0328, 0138, 0658, 0207, 0787, 0346, 0405, 0395
Dick Smith Electronics	0750	0698, 1556
Digatron	0751	0037, 0798, 0357
Digihome	0758	1667, 0469
Digiline	0759	0037, 0668, 0138, 0346
DigiMax	3808	0891
Digital Device	0770	1606
Digital Life	0772	0891
Digitek	0779	1709
Digitex	0780	0820
Digitor	0781	0037, 0698, 0456
Digix	3520	0453
Dikom	3391	3000, 3001
Dixi	0807	0037, 0699, 0086, 0138, 0060, 0112, 0730, 0330, 0281, 0386, 0346, 0357, 0788, 0367, 0798, 0395
DL	0810	0891, 1363, 0445, 1326
DMTech	0813	2001
Domeos	0817	0668
DongBao	4098	0699
Dongda	0820	0376, 0805, 0699, 0395
Donghai	0821	0805, 0376, 0395
DongHua	4099	0699
	0842	0808
Drean	0832	0037, 0138, 0346
DSE	0833	0698, 0820, 1556, 0138, 0792, 0170, 0344, 0456, 1682
DTS	0837	0699, 0386, 0060, 0395
Dual	0838	0037, 1037, 1163, 0061, 0138, 0101, 0330, 0104, 0658, 0198, 0346, 0352, 0845, 0788, 0404, 0357, 0419, 0272, 0744, 0759, 0798, 0409, 0407, 0459, 2032, 1324
Dual-Tec	3528	0061, 0699, 0658, 0651, 0101, 0404, 0409
Dumont	0840	0085, 0056, 0061, 0705, 0648, 0090, 0396, 0703, 0330, 0166, 0096, 0649, 0667, 0691, 0404, 0707, 0788
Duongjie	4101	0377, 0811, 0860
Durabrand	0842	0171, 0178, 0463, 1652, 0379
Dux	0843	0037, 0138, 0112, 0798, 0346, 0357
D-Vision	0684	0037, 0556, 0798, 0357, 1982
DVX	0847	0891
DX Antenna	0849	1817

Dynatron	0855	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357
Dynex	3476	1810, 2049, 0442
Dyon	4769	1166, 0111
E:max	0856	1324, 1531
Easy Living	0860	2104, 1709, 1613, 1217, 1308, 2005, 1666
Ecco	0864	0773
ECE	0865	0037, 0445
Elbe	0880	0037, 0556, 0138, 0741, 0330, 0141, 0790, 0751, 0349, 0651, 0406, 0788, 0346, 0663, 0665, 0409, 0844, 0426, 0610
Elbe-Sharp	3529	0790
Elcit	0883	0056, 0790, 0666, 0667, 0691
Electa	3530	0095, 0757
Electrion	4787	1585
ELECTRO TECH	3531	0699, 0658
Electroband	0888	0000
Electrograph	0889	1755
Electrohome	0890	0463
Electronic	4521	0658
Elekta	0895	0395, 0405
Elektra	0896	1661, 0411, 0151
Element	3477	0442
Elfunk	0899	1037, 1208
ELG	0900	0037, 0138, 0346, 0798, 0357
Elin	0902	0037, 0061, 0086, 0138, 0096, 0328, 0658, 0112, 0060, 0704, 0730, 0649, 0386, 0651, 0845, 0347, 0346, 0357, 0419, 0787, 0367, 0707, 0794, 0798, 0548, 0395
Elite	0903	0037, 0064, 0086, 0138, 0124, 0730, 0349, 0346, 0406, 0663
Elmak	0907	0703, 0101, 0649, 0667
Elonex	4019	1776, 0470
Elta	0910	0699, 0060, 0658, 0386, 0328, 0347, 0787, 0794, 0395, 0405
Emerson	0917	0037, 0171, 0178, 0463, 0668, 0020, 1394, 1661, 1864, 0138, 0090, 0056, 0741, 0648, 0107, 0207, 0655, 0346, 0396, 0357, 0691, 0666, 0361, 0760, 0359, 0367, 0798, 0800, 0801, 0442, 1909, 0486
e-motion	3496	1709
Emperor	0921	0411, 0151
Energy Sistem	0926	0394
Envision	0933	1365, 1589
Enzer	0934	0753, 0860
Epson	0937	0235, 0672, 0674
Erisson	4057	1682
Erres	0942	0037, 0086, 0138, 0065, 0730, 0112, 0346, 0390, 0357, 0798, 0367
ESA	0943	0171, 0812
ESC	0945	0037, 0330, 0138, 0788, 0346, 0798, 0357
Ether	0948	0395
Etron	0949	0820, 0699, 0138, 0346, 0395
Eurofeel	0954	0692, 0330, 0788, 0405
EuroLine	0955	0138, 0092, 0112, 2050
Euroman	0956	0037, 0138, 0741, 0086, 0061, 0730, 0151, 0692, 0328, 0330, 0787, 0788, 0346, 0347, 0794, 0357, 0404, 0798, 0411, 0367, 0405
Europa	0957	0037, 0138, 0346, 0798, 0357, 0367
Europhon	0959	0037, 0061, 0138, 0283, 0086, 0703, 0328, 0330, 0730, 0666, 0101, 0649, 0710, 0667, 0787, 0788, 0346, 0404, 0790
Evelux	4783	0848
Evesham	0972	1667, 0469, 1606, 1536
Evolution	0973	1756
Excello	0975	1037
Expert	0976	0117, 0218, 0409, 0651
Exquisit	0978	0037, 0138, 0346, 0357, 0798, 0367
Fagor Life	4102	0138, 0346
Feilang	0990	0805, 0376, 0395
Feilu	0991	0376, 0805, 0804, 0835, 0395
Feiyan	0992	0692, 0405, 0417
Feiyue	0993	0376, 0805, 0804, 0835, 0839, 0395
Fenmenti	4103	0798, 0357
Fenner	0994	0699, 0658, 0386, 0060, 0356, 0797, 0395
Ferguson	0996	0037, 0195, 0560, 0625, 1037, 0138, 0414, 0112, 0108, 0109, 0187, 0367, 0153, 0467, 0721, 0729, 0732, 0739, 0844, 0400, 0407, 0399, 0548, 0418, 1916, 2053, 1954

Fidelis	4522	0658
Fidelity	0998	0037, 0171, 0512, 0061, 0138, 0328, 0033, 0071, 0207, 0754, 0787, 0346, 0347, 0756, 0361, 0801, 0802, 0357, 0364, 0794, 0798, 0417, 0405
Filmnet	0999	0817
Filsai	1000	0330, 0788
Finlandia	1003	0208, 0071, 0293, 0365, 0754, 0122, 0548, 0407
Finlux	1004	0037, 0556, 0020, 1556, 1667, 0044, 0085, 0056, 0061, 0705, 0138, 0090, 0086, 0098, 0293, 0703, 0096, 0166, 0330, 0101, 0396, 0655, 0790, 0112, 0170, 0656, 0649, 0704, 0730, 0691, 0346, 0671, 0667, 0693, 0359, 0367, 0725, 0365, 0404, 0426, 0707, 0750, 0788, 0800, 1585, 0469, 0437, 0480, 0421, 0450, 0078
Fintec	1006	1982
Firstar	1007	0395
Firstline	1008	0037, 0208, 0556, 0668, 0020, 1037, 1363, 0061, 0699, 0086, 0099, 0138, 0060, 0293, 0328, 0330, 0127, 0165, 0658, 0346, 0356, 0347, 0730, 0386, 0179, 0352, 0666, 0364, 0357, 0845, 0359, 0667, 0797, 0787, 0788, 0365, 0367, 0404, 0711, 0794, 0419, 0413, 0798, 0800, 0802, 0426, 0844, 0395, 1909, 0450, 1308
Fisher	1009	0293, 0056, 0061, 0741, 0096, 0330, 0648, 0172, 0101, 0122, 0713, 0262, 0365, 0691, 0661, 0404, 0419, 0845, 0707, 0716, 0723, 0788
Flint	1014	0037, 0086, 0138, 0346, 0349, 0293, 0730, 0357, 0236, 0367, 0406, 0365, 0798, 0663, 0427, 0610, 0405
FNR	1016	0667
Formenti	1023	0037, 0012, 0044, 0061, 0056, 0090, 0138, 0328, 0101, 0655, 0691, 0102, 0725, 0651, 0112, 0750, 0758, 0787, 0347, 0364, 0416, 0802, 0367, 0486
Formenti-Phoenix	1024	0328, 0138, 0655, 0347, 0787, 0794
Fortress	1027	0012, 0056, 0691, 0398
Fraba	1030	0037, 0138, 0741, 0346, 0352, 0357, 0798, 0367
France Telecom	1033	0827
Friac	1040	0037, 0138, 0741, 0346, 0798, 0357, 0395, 0425, 0430, 0610
Frontech	1042	0692, 0699, 0207, 0099, 0658, 0071, 0060, 0386, 0072, 0845, 0666, 0330, 0754, 0419, 0788, 0755, 0405, 0395
Fuchsware	3915	0445
Fujicom	1048	1709
Fujitsu	1052	0809, 0330, 0293, 0117, 0667, 0404, 0124, 0693, 0788, 0452, 0395
Fujitsu General	1053	0330, 0293, 0788, 0365, 0395
Fujitsu Siemens	1054	1163, 1666, 1298, 0450
Funai	1056	0668, 0000, 0171, 0020, 1037, 1271, 1394, 1817, 0692, 0165, 0172, 0658, 0442, 0443, 0413, 0711, 0405, 1666, 1595, 0417, 1505, 0298
Furi	1057	0405, 0417
Furichi	1058	0860
FUTEK	3960	0762
Futronic	1061	0860, 0405
Gaba	4059	1037
Galaxi	1068	0037, 0138, 0224, 0346, 0667, 0741
Galaxis	1069	0037, 0138, 0741, 0346, 0357, 0367, 0224, 0798, 0667
Galeria	3633	0658, 0395
Gangtai	4104	0811
Ganxin	1072	0835, 0839
Gateway	1076	1755, 1756
GBC	1078	0699, 0138, 0293, 0101, 0647, 0658, 0386, 0170, 0060, 0356, 0349, 0713, 0124, 0797, 0663, 0406, 0395
GE	1081	0178, 0560, 0625, 1447, 1454, 0407, 0398, 0400
Geant Casino	1082	0218
GEC	1083	0037, 0061, 0138, 0033, 0086, 0072, 0073, 0293, 0330, 0107, 0730, 0647, 0790, 0693, 0112, 0845, 0346, 0788, 0357, 0760, 0724, 0367, 0365, 0404, 0419, 0755, 0798
Geloso	1087	0699, 0060, 0071, 0658, 0386, 0124, 0356, 0101, 0666, 0754, 0797, 0395
General	1090	0846, 0400
General Electric	1091	0407
General Technic	1095	0699, 0386, 0658, 0060, 0395
Genesis	1096	0037, 0395
Genexxa	1097	0037, 0064, 0072, 0086, 0138, 0124, 0730, 0346, 0349, 0663, 0357, 0406, 0755, 0798, 0417, 0395
Gericom	1103	1721, 1298, 1217, 0453, 0450
GFM	3820	0171, 0442
G-Hanz	3397	1363
Giant	1113	0330, 0788, 0395
GM	4523	0658
GMG	4524	0658
Gold	3823	1833, 1770
Goldfunk	1135	0668
GoldHand	1136	0658, 0328, 0787, 0347, 0794
Goldline	1138	0138, 0346
GoldStar	1140	0037, 0178, 0020, 0138, 0061, 0699, 0086, 0099, 0160, 0658, 0741, 0060, 0071, 0730, 0101, 0666, 0701, 0328, 0330, 0112, 0113, 0742, 0332, 0386, 0346, 0787, 0788, 0754, 0347, 0352, 0357, 0789, 0359, 0364, 0794, 0404, 0802, 0798, 0367, 0800, 0395, 0400, 0437

Goodmans	1142	0037, 0556, 0560, 0625, 0634, 0668, 0020, 1037, 1163, 1523, 1667, 0692, 0138, 0699, 0086, 0033, 0174, 0713, 0293, 0238, 0112, 0213, 0330, 0207, 0127, 0790, 0658, 0332, 0060, 0356, 0271, 0274, 0386, 0730, 0326, 0346, 0352, 0664, 0357, 0660, 0361, 0693, 0359, 0661, 0367, 0160, 0404, 0365, 0392, 0797, 0764, 0772, 0788, 0779, 0780, 0785, 0789, 0798, 0800, 0801, 0861, 0437, 0425, 0407, 1909, 0405, 0395, 0480, 0453, 1308, 0469, 1682, 1720, 2053, 2127, 1983
Gorenje	1144	0741
GP	1147	0753
GPM	1149	0064, 0138, 0124, 0658, 0406, 0346, 0663
Gradiente	1151	0037, 0138, 0346
Graetz	1152	0020, 1163, 0072, 0138, 0107, 0760, 0207, 0755, 0801, 0346, 0361
Granada	1154	0037, 0108, 0208, 0226, 0560, 0044, 0061, 0033, 0138, 0071, 0086, 0076, 0187, 0293, 0330, 0713, 0122, 0790, 0476, 0102, 0080, 0112, 0191, 0284, 0730, 0734, 0693, 0661, 0671, 0344, 0725, 0346, 0357, 0847, 0365, 0390, 0367, 0404, 0788, 0754, 0758, 0422, 0718, 0429, 0723, 0750, 0218, 0792, 0798, 0402, 0399, 0421, 0401, 0407, 0548
Grandin	1156	0037, 0556, 0668, 0020, 1037, 0699, 0138, 0064, 0657, 0151, 0095, 0112, 0356, 0797, 0663, 0349, 0124, 0346, 0757, 0357, 0411, 0798, 0359, 0800, 0367, 0395, 0610, 0437, 0453
Great Wall	4105	0793, 0356
Gronic	1160	0330, 0788
Grundig	1162	0037, 0195, 0556, 0706, 1223, 1667, 2007, 0027, 0138, 0033, 0705, 0085, 0044, 0468, 0741, 0125, 0396, 0232, 0697, 0357, 0367, 0326, 0346, 0116, 0671, 0725, 0745, 0257, 0124, 0750, 0798, 0799, 0855, 1093, 0508, 2127, 1037, 0418, 0395, 1916, 1308, 0178, 0407, 0469, 2053, 0046, 0186, 0261, 0264, 0295, 0336, 0384
Grunkel	1164	1163
GVA	3510	1363
H & B	1171	0450, 2001
Haaz	1172	0706
Haier	1175	0698, 0037, 0508, 0891, 0896, 1083, 1423, 2449, 0849, 0433, 0405, 1169
Haihong	1176	0376, 0805, 0699, 0896, 0808, 0395
Haile	4106	0806
Haiyan	1177	0804, 0835, 0839, 0692, 0405, 0417
Halcro	1178	0805
Halifax	1179	0692, 0061, 0328, 0330, 0787, 0788, 0794, 0347, 0404, 0405
Hallmark	1180	0178
Hammerstein	3636	0405
Hampton	1183	0061, 0328, 0330, 0787, 0788, 0794, 0802, 0347, 0404, 0364
Hankook	1188	0178
Hanns.G	3478	1613
Hannspree	1189	1776, 1072, 1613, 0470
Hanseatic	1190	0037, 0556, 0625, 0634, 0020, 0138, 0741, 0061, 0699, 0151, 0086, 0751, 0060, 0230, 0101, 0730, 0107, 0330, 0713, 0696, 0386, 0845, 0112, 0711, 0760, 0788, 0344, 0346, 0357, 0359, 0367, 0404, 0792, 0411, 0416, 0419, 0798, 0800, 0413, 0425, 0395, 0450, 0486, 2001
Hantarex	1192	0037, 0699, 0138, 0658, 0060, 0386, 0346, 0357, 0790, 0367, 0798, 0395
Hantor	1193	0037, 0138, 0346, 0357, 0798, 0367
Harwa	1203	0773
Harwood	1204	0037, 0138, 0060, 0346, 0386, 0357, 0367, 0798, 0395, 0417
Hauppauge	1206	0037, 0138, 0502, 0170, 0346, 0798, 0357
Havermy	1208	0398
HCM	1210	0037, 0692, 0138, 0060, 0222, 0699, 0061, 0151, 0095, 0330, 0658, 0224, 0386, 0346, 0349, 0795, 0357, 0367, 0404, 0788, 0663, 0406, 0411, 0757, 0798, 0395, 0417, 0405
Hema	1222	0060, 0386, 0330, 0788, 0404, 0395
Hemmermann	1223	0845, 0419
Heran	3828	1852
Hewlett Packard	1229	1494
HHB	1230	0800
Hicon	1232	1298
Hifivox	1233	0104, 0759, 0400
Higashi	1234	0328, 0787
Highlander	3829	1531
Highline	1236	0037, 0138, 0346, 0798, 0357, 0405
Hikona	1237	0349, 0663, 1983
HiLine	3533	0138, 0346
Hinari	1243	0037, 0208, 0699, 0138, 0033, 0086, 0060, 0064, 0713, 0124, 0112, 0127, 0386, 0658, 0349, 0346, 0357, 0367, 0730, 0162, 0406, 0221, 0661, 0725, 0663, 0122, 0798, 0395, 0418, 0405
Hisawa	1247	0020, 0064, 0151, 0095, 0218, 0349, 0236, 0359, 0411, 0406, 0124, 0663, 0757, 0800, 0427, 0610
Hisense	1249	0156, 0208, 0508, 0556, 0753, 0821, 0860, 1314, 1363, 2098, 2341, 0122, 0369, 0896, 0372, 0803, 0838, 0395, 0445, 1208
Hisonix	4525	0658
Hitachi	1251	1667, 0037, 0108, 0150, 0156, 0178, 0508, 0634, 1037, 1163, 1576, 1643, 2215, 2433, 0053, 0138, 0061, 0033, 0023, 0071, 0098, 0072, 0073, 0726, 0074, 0296, 0293, 0713, 0724, 0104, 0101, 0102, 0330, 0107, 0126, 0790, 0234, 0266, 0291, 0678, 0309, 0319, 0448, 0346, 0357, 0367, 0521, 0704, 0404, 0419, 0693, 0422, 0365, 0429, 0369, 0661, 0524, 0719, 0754, 0845, 0758, 0847, 0788, 0727, 0760, 0728, 0752, 0755, 0759, 0769, 0798, 0803, 0395, 0578, 0438, 0401, 0399, 0441, 1585, 2127, 0400, 0469, 0421, 0407, 0548, 0425, 0480, 0459, 0028, 0078, 0278, 0355, 0380
Hitachi Fujian	1252	0108, 0150, 0860, 0803, 0835, 0369, 0839, 0692, 0838, 0399, 0401, 0425

Hitec	1253	0698
Hitsu	1257	0347, 0794, 0395, 0610
Hoeher	1262	0020, 1163, 1556, 0359
Homita	4843	0798
Hongmei	1272	0374, 0376, 0805, 0460, 0804, 0692, 0835, 0839, 0395, 0398, 0405
Hongyan	1274	0835, 0692, 0405, 0417
Hornlyphon	1277	0037, 0086, 0138, 0730, 0346, 0357, 0367
Hoshai	1278	0064, 0236, 0349, 0124, 0406, 0663, 0427
Hotel TV	4107	0828
HP	1283	1494
Hua Tun	1286	0395
Huafa	1287	0803, 0805, 0369, 0395
Huanghaimei	1288	0805, 0376, 0395
Huanghe	1289	0376, 0805, 0804, 0896, 0835, 0839, 0395
Huanglong	1290	0805, 0376, 0395
Huangshan	1291	0376, 0805, 0806, 0804, 0835, 0839, 0692, 0395, 0405, 0417
Huanyu	1292	0213, 0061, 0328, 0356, 0797, 0460, 0787, 0347, 0794, 0364, 0692, 0374, 0802, 0804, 0835, 0838, 0839, 0405
Huaqiang	1293	0692, 0405, 0417
Huari	1294	0803, 0692, 0369, 0405, 0417
Hugoson	1297	1666, 1217
Huijiaban	4108	0377, 0860
Humax	1298	1295
Huodateji	1302	0833
Hygashi	1308	0061, 0328, 0330, 0787, 0788, 0794, 0347, 0404
Hyper	1309	0061, 0699, 0099, 0658, 0124, 0060, 0666, 0328, 0330, 0386, 0101, 0787, 0788, 0347, 0364, 0802, 0404, 0794, 0395
Hypson	1312	0037, 0556, 0668, 0020, 1037, 0086, 0138, 0061, 0151, 0730, 0095, 0236, 0692, 0330, 0112, 0346, 0788, 0357, 0757, 0404, 0798, 0367, 0411, 0800, 0359, 0218, 0427, 0405, 0437, 0486
Hyundai	1315	0698, 0753, 0860, 1037, 1523, 1556, 1681, 0435, 0706, 0850, 1326, 1531, 1770, 0405, 0456, 1606
Iberia	1320	0037, 0138, 0346, 0357, 0798, 0367
ICE	1324	0037, 0692, 0138, 0061, 0086, 0699, 0207, 0064, 0060, 0124, 0730, 0328, 0330, 0663, 0346, 0386, 0349, 0787, 0788, 0361, 0347, 0364, 0404, 0801, 0802, 0794, 0406, 0405, 0395
ICE/ITS	4526	0124
ICeS	1325	0328, 0124, 0347, 0787, 0349, 0663, 0802, 0364, 0406, 0794
ICT	1328	0459
iDEAL	3641	1556
IlSonic	1334	1613
Iiyama	1335	1217
Imperial	1346	0037, 0138, 0033, 0089, 0086, 0044, 0099, 0072, 0741, 0224, 0730, 0725, 0666, 0101, 0346, 0845, 0795, 0357, 0750, 0837, 0692, 0419, 0755, 0798, 0397
Imperial Crown	1347	0395, 0405, 0417
Indesit	1349	0705, 0709
Indiana	1350	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357, 0367
Ingelen	1354	0020, 0072, 0755, 0800, 0359, 0610
Ingersol	1355	0699, 0386, 0060
Ingersoll	3642	0395
Inno Hit	1358	1037, 1163, 0044, 0061, 0699, 0138, 0086, 0251, 0293, 0658, 0064, 0060, 0330, 0647, 0124, 0386, 0730, 0112, 0790, 0332, 0666, 0663, 0693, 0346, 0349, 0365, 0160, 0404, 0788, 0406, 0750, 0789, 0395, 0037, 0556, 1585
Innova	1359	0037
Innovation	1360	0692, 0119, 0699, 0138, 0207, 0113
Innowert	1362	1298
Inotech	1364	0773, 0820
Insignia	1368	0171, 1204, 1423, 1564, 2049, 1326
Inspira	4296	1556, 1324
INTER	4109	0832
Interactive	3534	0741, 0400
Interbuy	1376	0037, 0699, 0099, 0083, 0138, 0060, 0357, 0386, 0666, 0367, 0798, 0395, 0405
Interfunk	1377	0037, 0512, 0138, 0056, 0741, 0648, 0086, 0099, 0072, 0248, 0730, 0691, 0104, 0107, 0112, 0755, 0760, 0344, 0792, 0357, 0390, 0798, 0367, 0759, 0346, 0400
Internal	1379	0556, 0138, 0357, 0798, 0367, 0425, 1909
International	1380	0328, 0787
Intervision	1386	0037, 0138, 0692, 0083, 0741, 0061, 0703, 0330, 0151, 0207, 0346, 0349, 0236, 0357, 0666, 0404, 0367, 0788, 0649, 0406, 0411, 0667, 0663, 0427, 0798, 0405, 0486, 0395
IR	4110	0356, 0138, 0357, 0797, 0796, 0364, 0293, 0365, 0802, 0798, 0367

Irradio	1396	0037, 0044, 0699, 0138, 0086, 0207, 0064, 0658, 0656, 0060, 0332, 0124, 0112, 0730, 0386, 0666, 0346, 0671, 0349, 0663, 0361, 0357, 0750, 0789, 0406, 0798, 0801, 0395
IRT	1397	0698, 1661
Isukai	1402	0037, 0064, 0138, 0124, 0349, 0346, 0151, 0411, 0406, 0357, 0367, 0663, 0798
IT	4111	0831
ITC	1404	0061, 0788, 0330, 0101, 0404
ITS	1405	0037, 0064, 0086, 0138, 0207, 0328, 0151, 0730, 0095, 0663, 0787, 0124, 0346, 0349, 0361, 0802, 0801, 0347, 0757, 0357, 0794, 0411, 0406, 0364, 0798, 0405, 0395
ITT	1406	0208, 0699, 0664, 0072, 0718, 0102, 0758, 0845, 0760, 0847, 0107, 0755, 0080, 0419, 0429, 0480, 0548, 0421, 0610
ITT Nokia	1407	0208, 0651, 0548, 0421, 0480, 0610
ITV	1408	0037, 0699, 0138, 0092, 0666, 0112, 0797, 0356, 0113, 0346, 0798, 0357, 0367, 0405
JCB	1421	0000
JDV	1423	1982
Jean	1424	0156, 0395
JEC	1426	0660, 0761, 0392, 0110
JGC	1434	1709
Jiahua	1435	0377, 0806, 0860, 0833
JiaLiCai	1436	0699, 0805, 0692, 0395, 0405, 0417
Jian Sheng	4112	0814
Jinfeng	1438	0208, 0226, 0804, 0833, 0835, 0402
Jinhai	1439	0374, 0460
Jinlipu	4113	0807
Jinque	1440	0805, 0835, 0692, 0395, 0405, 0417
Jinta	1441	0805, 0839, 0692, 0395, 0405, 0417
Jinxing	1442	0037, 0156, 0556, 0698, 0821, 0122, 0369, 0804, 0806, 0372, 0811, 0803, 0692, 0835, 0395, 0405
Jinxingban	4114	0814
JMB	1445	0556, 0634, 0425, 0418
JNC	1446	0896, 1536
Jocel	1448	0712
JTV	3645	0860
Jubilee	1460	0556
Juhua	1461	0835, 0839, 0692, 0405, 0417
JVC	1464	1818, 0653, 1253, 0463, 0508, 0650, 0731, 1601, 0021, 0049, 0079, 0033, 0086, 0713, 0207, 0109, 0349, 0114, 0361, 0795, 0193, 0194, 0406, 0661, 0362, 0730, 0529, 0663, 0856, 0739, 0801, 1074, 1058, 0133, 0398, 0088, 0167, 0242, 0256, 0256
Kaige	1470	0805, 0835, 0839, 0692, 0395, 0405, 0417
Kaisui	1471	0037, 0061, 0699, 0060, 0138, 0064, 0124, 0328, 0330, 0658, 0095, 0151, 0386, 0236, 0346, 0347, 0349, 0357, 0787, 0788, 0404, 0364, 0663, 0367, 0757, 0802, 0411, 0406, 0794, 0798, 0427, 0395
Kambrook	1473	0405
Kamosonic	3535	0061
Kamp	1475	0061, 0328, 0787, 0794, 0802, 0347, 0364
Kangchong	1476	0374, 0460
Kanghua	1477	0896
Kangli	1478	0805, 0835, 0837, 0839, 0692, 0395, 0405
Kangwei	4115	0377, 0814, 0860
Kangyi	1479	0699, 0692, 0805, 0395, 0405, 0417
Kansas Technologies	1481	0762
Kapsch	1483	0072, 0096, 0117, 0409, 0651, 0755
Karcher	1484	0020, 1556, 0138, 0061, 0699, 0741, 0658, 0151, 0112, 0704, 0346, 0359, 0411, 0665, 0667, 0800, 0610, 0405, 1982, 1308
Kathrein	1486	0556, 0138, 0453
Kawa	1487	0207, 0801, 0361
Kawasho	1489	0328, 0787, 0347, 0794
Ken Brown	1499	0463
Kendo	1500	0037, 1037, 0138, 0071, 0741, 0658, 0703, 0127, 0346, 0666, 0352, 0357, 0367, 0754, 0665, 0667, 0426, 0798, 0610, 1585, 0486, 0459
Kennedy	1504	0101, 0651
Kennex	1505	1037
Kenstar	3756	2388
Keymat	3499	1326
Khind	1511	0706, 0896
KIC	1512	0330, 0788
Kingsley	1520	0061, 0328, 0787, 0794, 0802, 0347, 0364
Kiota	1522	0207
Kioto	1523	0556, 0706
Kiton	1525	0037, 0668, 0798, 0357

Klarmax	4527	0033
KLL	1531	0037
Kneissel	1535	0037, 0556, 0138, 0741, 0141, 0356, 0346, 0797, 0751, 0357, 0367, 0844, 0231, 0798, 0409, 0426, 0610, 0425
Kobra	1537	1298
Kolin	1541	0037, 0108, 0150, 0891, 1331, 1610, 1755, 1217, 0399
Kolster	1543	0037, 0086, 0138, 0730, 0346, 0367
Kongque	1545	0805, 0835, 0839, 0692, 0395, 0405
Konichi	1546	0395
Konig	1547	0037, 0792, 0344
Konka	1548	0037, 0020, 0064, 0207, 0138, 0346, 0349, 0124, 0663, 0361, 0801, 0806, 0357, 0808, 0798, 0406, 0795, 0799, 0359, 0804, 0800, 0444
Korpel	1552	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357, 0367
Korting	1554	0090, 0741, 0056, 0648, 0155, 0416, 0691
Kosmos	1557	0037, 0138, 0346, 0367
Kotron	1560	0417, 0405
Koyoda	1561	0699, 0060, 0395
Kross	1571	1536
KTV	1572	0061, 0330, 0788
Kuaile	1573	0805, 0692, 0395, 0405, 0417
Kulun	1577	0395
Kunlun	1578	0208, 0226, 0804, 0833, 0835, 0837, 0692, 0402, 0405
Kuro	1579	0210
Kyoshu	1583	0795, 0417, 0405
Kyoto	1585	0328, 0330, 0787, 0788
L&S Electronic	1588	0020, 0800, 0359
LaSAT	1597	0741, 0486
Lavis	1602	1037, 1363
Layco	4117	0138, 0365, 0367, 0293
Leader	1604	0395
Lecson	1606	0037, 0138, 0346, 0798, 0357
Legend	1609	0395
Lenco	1615	0037, 1037, 0699, 0138, 0346, 0060, 0386, 0356, 0096, 0797, 0357, 0798, 1147, 0395, 1983
Lenoir	1617	0658, 0699, 0386, 0061, 0060, 0395
Lentec	3405	1531
Lerico	4528	0649
Lesa	1622	0099, 0666
Lexsor	1626	1507
Leyco	1627	0037, 0692, 0086, 0138, 0293, 0112, 0346, 0357, 0165, 0730, 0647, 0693, 0413, 0711, 0798, 0405
LG	1628	1423, 0178, 0037, 0108, 0556, 0698, 0020, 1681, 2182, 0741, 0061, 0699, 0138, 0086, 0267, 0099, 0071, 0471, 0092, 0101, 0112, 0113, 0492, 0328, 0330, 0220, 0060, 0730, 0386, 0276, 0332, 0701, 0666, 0643, 0347, 0742, 0160, 0346, 0357, 0787, 0788, 0404, 0754, 0359, 0789, 0794, 0798, 0800, 1036, 1083, 1090, 1084, 1139, 0957, 1027, 1075, 1078, 1174, 1721, 0395, 0399, 0400, 0437, 0029, 0035, 0039, 0045, 0135, 0176, 0273
LG/Goldstar	3536	0138, 0038
Liesenk	3537	0112
Liesenk & Tter	1630	0138, 0346, 0798, 0357, 0367
Liesenkotter	1631	0037, 0138, 0346
Life	3538	0692, 0119, 0699, 0138, 0207, 0113
Lifetec	1633	0037, 0668, 0020, 1037, 0119, 0699, 0138, 0207, 0060, 0113, 0692, 0346, 0356, 0349, 0386, 0797, 0663, 0357, 0359, 0367, 0798, 0406, 0800, 0459, 2001, 0395, 0430, 0405
Lihua	1636	0835
Lloyds	3539	0060
Lloyd's	1648	0386, 0395
Local Calcutta TV	1651	1208
Local Chennai TV	1652	0405, 0395
Local India TV	1653	0208, 0207
Local Malaysia TV	1656	0698
Lodos	1659	1037
Loewe	1660	0037, 0512, 0633, 1884, 0014, 0090, 0741, 0158, 0751, 0248, 0790, 0199, 0311, 0138, 0346, 0747, 0765, 0556, 0430, 0084, 0260
Loewe Opta	3540	0056, 0648, 0086, 0654, 0138, 0112, 0730, 0691, 0346, 0357, 0798, 0367
Logik	1661	0698, 0773, 1037, 0200, 0207, 0796, 0388, 0361, 0801, 1865, 0395, 0405, 0453, 1217
Logix	1663	0668
Longjiang	1664	0804, 0692, 0835, 0405, 0417
Luker	1673	1982
Luma	1674	1037, 0071, 0107, 0138, 0060, 0386, 0117, 0112, 0754, 0760, 0651, 0346, 0409, 0426, 0395

Lumatron	1676	0037, 0071, 0086, 0730, 0138, 0107, 0754, 0330, 0760, 0788, 0112, 0346, 0798, 0404, 0357, 0409, 0405
Lux May	1680	0037, 0086, 0730, 0138, 0346, 0798, 0357, 0395
Luxor	1683	0208, 1037, 1163, 0061, 0648, 0033, 0071, 0330, 0664, 0681, 0107, 0332, 0160, 0419, 0845, 0754, 0760, 0788, 0422, 0728, 0789, 0480, 0548, 0421
LXI	1686	0156, 0178
M Electronic	1688	0037, 0195, 0512, 0634, 0020, 1652
Maaz	4529	0033
Madison	1698	0037, 0798, 0357
Magnadyne	1702	0090, 0056, 0648, 0099, 0703, 0101, 0658, 0649, 0790, 0666, 0112, 0691, 0667
Magnafon	1703	0089, 0061, 0044, 0328, 0703, 0283, 0790, 0649, 0655, 0347, 0671, 0725, 0364, 0667, 0750, 0787, 0794, 0802
Magnavox	1706	0706, 0753, 1365, 1454, 1866, 1172, 0138, 0796, 0346, 0445, 0054
Magnum	1709	0037, 0020, 0692, 0119, 0699, 0138, 0207, 0113, 0357, 0359, 0798, 0367, 0800, 0437
Mandor	1717	0692, 0405
Manesth	1718	0037, 0692, 0138, 0086, 0061, 0127, 0112, 0730, 0330, 0660, 0346, 0357, 0788, 0367, 0404, 0416, 0798, 0392, 0413, 0405
Manhattan	1719	0037, 0668, 1037, 0138, 0346, 0798, 0357
Maqma	1722	1298, 1709, 1606
Marantz	1724	0037, 0556, 1454, 0086, 0138, 0112, 0730, 0170, 0792, 0344, 0798, 0346, 0367, 0357, 0417
Marelli	1729	0090, 0056, 0691
Mark	1731	0037, 0020, 0086, 0138, 0060, 0730, 0328, 0330, 0112, 0346, 0356, 0797, 0787, 0386, 0788, 0347, 0352, 0794, 0357, 0798, 0359, 0800, 0404, 0367, 0395, 0437
Marks and Spencer	3585	1770
Mascom	1738	1556
Master's	1742	0425
Mastro	1743	0698, 0706, 1556, 0445
Masuda	1744	0037, 0330, 0207, 0788, 0663, 0349, 0395, 0405
Matsui	1750	0037, 0195, 0208, 0556, 0020, 1037, 1667, 2007, 0061, 0699, 0138, 0060, 0033, 0071, 0086, 0710, 0293, 0200, 0660, 0713, 0106, 0330, 0112, 0122, 0790, 0110, 0127, 0187, 0386, 0207, 0245, 0143, 0658, 0357, 0346, 0388, 0361, 0162, 0165, 0730, 0367, 0761, 0359, 0179, 0404, 0693, 0201, 0745, 0419, 0845, 0365, 0236, 0279, 0320, 0392, 0661, 0754, 0796, 0788, 0027, 0413, 0427, 0711, 0782, 0798, 0800, 0801, 0395, 0418, 1916, 1666, 0453, 0469
Matsushita	1751	0650, 0091, 0119
Maxam	3651	0405
Maxdorf	1756	0773, 1276, 0405
Maxell	4477	0658
Maxent	1757	1755
Maxim	1759	1556, 1982
Maxwell	1763	0033
MCE	1766	0395
McMichael	1768	0073, 0724
Meck	1775	0698, 0891
Mediator	1784	0037, 0556, 0086, 0138, 0065, 0112, 0730, 0390, 0346, 0357, 0367, 0798
Mediencom	1786	0138
Medion	1787	0037, 0512, 0556, 0668, 0698, 0020, 1037, 1556, 1667, 0119, 0699, 0138, 0207, 0692, 0113, 0346, 0352, 0357, 0798, 0359, 0800, 0367, 0450, 0459, 0453, 1916, 2001, 0469
Medison	1788	0138, 0346
Megas	1792	0610
Megatron	1795	0178
MEI	1796	1037
Meile	1797	0835, 0839, 0692, 0405, 0417
MeiShi	4118	0762
Meletronic	3654	0061, 0699, 0060, 0086, 0083, 0138, 0098, 0081, 0072, 0104, 0096, 0648, 0328, 0330, 0213, 0112, 0356, 0153, 0386, 0207, 0239, 0730, 0704, 0346, 0347, 0248, 0357, 0359, 0664, 0681, 0364, 0666, 0367, 0404, 0426, 0797, 0707, 0755, 0759, 0787, 0788, 0794, 0798, 0800, 0802, 0395, 0400, 0407, 0480
Melvox	1799	0218
Memorex	1800	0150, 0178, 0463, 1037, 0699, 0386, 0060, 0395
Memory	1801	1983
Memphis	1802	0699, 0386, 0188, 0060, 0293, 0693, 0395
Mengmei	4119	0839
Mercury	1804	0037, 0138, 0060, 0386, 0346, 0357, 0798, 0395, 0405
Mermaid	1806	0037
Merritt	3655	0548
Metronic	1809	0625
Metz	1810	0037, 0195, 0668, 1163, 0056, 0090, 0138, 0357, 0168, 0367, 0648, 0204, 0027, 0483, 0257, 0691, 0697, 0735, 0798, 0799, 1533, 0746, 0447
MGA	1811	0150, 0178, 0124
Micromaxx	1822	0037, 0668, 0020, 1037, 0119, 0699, 0138, 0692, 0207, 0113, 0346, 0357, 0798, 0450, 1324, 2001
Microspot	3849	1614

Microstar	1827	0692, 0119, 0699, 0138, 0207, 0113, 0450
MicroTEK	1829	0820, 0860, 0405
Mikomi	1833	1037, 0441
Minato	1835	0037, 0798, 0357
Minerva	1838	0108, 0195, 0085, 0705, 0044, 0257, 0396, 0790, 0697, 0671, 0027, 0750, 0399
Ministry Of Sound	4247	1667, 0469
Minoka	1840	0037, 0086, 0138, 0222, 0730, 0346, 0357, 0798, 0417
Mirai	1849	1666, 1852
Mitsai	3851	1556
Mitsubishi	1855	0037, 0108, 0150, 0178, 0512, 0556, 0836, 1037, 1250, 0056, 0138, 0033, 0086, 0200, 0090, 0713, 0069, 0100, 0346, 0357, 0248, 0476, 0648, 0367, 0661, 0658, 0544, 0257, 0490, 0691, 0697, 0730, 0798, 0399, 0398
Mivar	1857	0609, 0160, 0741, 0251, 0061, 0328, 0330, 0725, 0044, 0751, 0750, 0332, 0787, 0788, 0347, 0789, 0790, 0364, 0794, 0802
MoDeng	4120	0762
Monaco	1868	0395
Monix	4298	0445
Moree	4565	0037
Morgans	3970	0138, 0346, 0798, 0357
Morgan's	1875	0037
Motion	1877	0089, 0725, 0044, 0750
Motorola	1878	0398
MTC	1889	0512, 0741, 0328, 0248, 0787, 0845, 0347, 0419, 0794
MTEC	1890	0710
MTlogic	1892	0020, 0800, 0359, 1308, 2050
Mudan	1896	0208, 0226, 0692, 0377, 0860, 0833, 0805, 0835, 0395, 0402, 0405, 0417
Multistandard	1904	0667
Multisystem	4121	0138, 0112
Multitec	1906	0037, 0668, 1037, 1556, 0798, 0802, 0364, 0357, 0486, 1982
Multitech	1907	0037, 0138, 0060, 0699, 0061, 0741, 0089, 0703, 0099, 0071, 0658, 0713, 0726, 0124, 0101, 0328, 0386, 0330, 0666, 0112, 0667, 0845, 0346, 0725, 0347, 0357, 0754, 0787, 0788, 0404, 0419, 0794, 0798, 0395, 0486, 0405
Murphy	1911	0061, 0293, 0328, 0102, 0096, 0347, 0758, 0787, 0364, 0707, 0365, 0802, 0794, 2005
Musikland	1915	0349, 0663
Mx Onda	1919	1983
Myryad	1922	0556
NAD	1926	0037, 0156, 0178, 0760, 0107
Naiko	1930	0037, 0753, 0138, 0346, 0798, 0357, 1982
Nakimura	1933	0037, 0138, 0346, 0367
Nanbao	1934	0805, 0692, 0395, 0405, 0417
Nansheng	1935	0804, 0835, 0692, 0405, 0417
Naonis	1936	0754, 0071
Narita	1939	1982
NAT	1941	0226, 0402
National	1942	0208, 0226, 0508, 0129, 0734, 0346, 0357, 0367, 0402
NEC	1950	0156, 0178, 0508, 0653, 1797, 0138, 0330, 0658, 0713, 0356, 0887, 0346, 0661, 0797, 0788, 0796, 0416, 1852, 0395, 1775, 0405, 0417, 0425, 0434
Neckermann	1951	0037, 0556, 0138, 0090, 0061, 0056, 0086, 0741, 0697, 0071, 0330, 0648, 0224, 0112, 0170, 0244, 0730, 0666, 0691, 0346, 0845, 0404, 0795, 0419, 0367, 0788, 0754, 0357, 0426, 0798
NEI	1952	0037, 1037, 0086, 0138, 0112, 0207, 0730, 0188, 0346, 0361, 0801, 0357, 0798, 0367
NEO	3947	0444, 1324
Nesco	1960	0099, 0666
Netsat	1966	0037, 0138, 0346, 0798, 0357
NetTV	1967	1755
Network	1968	0188
Neufunk	1970	0037, 0556, 0020, 0138, 0060, 0346, 0386, 0357, 0359, 0367, 0798, 0800, 0395, 0610
New Tech	1979	0037, 0556, 0699, 0086, 0138, 0060, 0730, 0330, 0386, 0346, 0357, 0788, 0404, 0798, 0395, 0407
New World	1980	0064, 0663, 0349, 0124, 0406
Newave	1981	0178, 0395, 0398
Nicamagic	1994	0061, 0328, 0787, 0794, 0347
Nikai	4566	1163
Nikkai	1998	0037, 0692, 0138, 0061, 0086, 0660, 0064, 0293, 0124, 0060, 0328, 0330, 0110, 0112, 0188, 0730, 0761, 0346, 0347, 0386, 0349, 0661, 0693, 0364, 0663, 0357, 0787, 0788, 0365, 0367, 0404, 0392, 0406, 0794, 0802, 0798, 0405, 0395
Nikkei	1999	0020
Nikko	2000	0178
Nimbro	4065	2104
Nintaus	2006	0891

Noblex	2013	0037, 0138, 0658, 0346, 0405
Noblisko	2014	0089, 0061, 0648, 0044, 0705, 0703, 0328, 0649, 0396, 0655, 0656, 0347, 0671, 0364, 0667, 0725, 0750, 0787, 0794, 0802
Nogamatic	2016	0104, 0759, 0400
Nokia	2017	0208, 0239, 0072, 0681, 0664, 0356, 0080, 0102, 0797, 0845, 0107, 0847, 0718, 0758, 0760, 0755, 0419, 0429, 0421, 0480, 0548, 0610, 0400
Norcent	2020	1365, 1589
Nordic	2021	0330, 0788
Nordmende	2022	0037, 0195, 0560, 0020, 0891, 1163, 1667, 2007, 0056, 0138, 0726, 0086, 0709, 0031, 0072, 0691, 0153, 0730, 0104, 0346, 0357, 0359, 0727, 0027, 0755, 0798, 0759, 0800, 0400, 0407, 2001, 0418, 1585, 0469, 0192
Nordvision	3543	0112
Normerel	2024	0037, 0798, 0357
Nortek	3862	0668
Novatronic	2035	0037, 0138, 0356, 0797, 0346, 0357, 0798, 0367
Novex	4567	1523
Novita	2037	1585
Nu-Tec	2048	0698, 0820, 0821, 0405
O.K.Line	4301	1037, 1324
Oceanic	2061	0208, 0657, 0072, 0107, 0671, 0760, 0755, 0218, 0413, 0421, 0548, 0480, 2001
Odeon	2064	0405
Odys	4066	0115
Okana	4122	0138, 0367
Okano	2065	0037, 0138, 0741, 0346, 0357, 0293, 0798, 0405, 0395
OKI	4067	0078
Olevia	2067	1144, 1331, 1610
Omega	2072	0405
Omni	2074	0698, 0891, 0445
ONCEAS	3544	0658, 0061
Onei	4302	1667, 0469
Onida	2081	0653, 1253, 2396
Onimax	2082	0020, 0800, 0359
Onn	3663	1667, 1709, 0469, 1770
Onwa	2087	0207, 0349, 0361, 0801, 0287, 0663, 0406
Onyx	3864	1709, 1770
Opera	2090	0037, 0138, 0346, 0357, 0798
Optimus	2095	0650
Optonica	2099	0398
Orava/OTF	4530	0658
Orbit	2103	0086, 0138, 0730, 0346, 0357, 0798
Orion	2111	0037, 0463, 0556, 0020, 1037, 2007, 0699, 0017, 0086, 0200, 0138, 0033, 0112, 0113, 0790, 0140, 0127, 0162, 0386, 0060, 0165, 0316, 0179, 0730, 0388, 0346, 0238, 0357, 0367, 0416, 0201, 0796, 0359, 0735, 0667, 0711, 0413, 0798, 0800, 2032, 2005, 1954, 0418, 0430, 0395, 0405, 0417, 1916, 0453, 2001, 0167, 0203, 0259
Orline	2113	0037, 0138, 0349, 0346, 0357, 0406, 0798, 0367, 0663
Ormond	2114	0668, 1037, 0138, 0113
Orsowe	2116	0790
Osaki	2118	0037, 0556, 0692, 0138, 0061, 0222, 0293, 0064, 0330, 0124, 0710, 0356, 0349, 0346, 0663, 0693, 0357, 0797, 0365, 0367, 0788, 0404, 0000, 0406, 0798, 0405, 0417
Oscar	2120	0851
Osio	2121	0037, 0332, 0138, 0789, 0346, 0798, 0357, 0367
Oso	2122	0064, 0124, 0349, 0663, 0406
Osume	2123	0037, 0349, 0138, 0357, 0293, 0367, 0365, 0693, 0103, 0406, 0661, 0663, 0798, 0716
Otake	2124	0174
Otic	2125	1983
Otto Versand	2126	0037, 0195, 0226, 0512, 0556, 0061, 0012, 0086, 0138, 0713, 0095, 0210, 0101, 0104, 0000, 0330, 0107, 0697, 0658, 0790, 0127, 0248, 0244, 0730, 0257, 0112, 0666, 0284, 0344, 0845, 0404, 0346, 0788, 0357, 0760, 0416, 0419, 0367, 0661, 0027, 0413, 0757, 0759, 0792, 0798, 0407, 0398, 0400, 0402, 0395
Oulin	4123	0377, 0860
Pacific	2135	0556, 0020, 1037, 0800, 0359, 0459, 0418, 1324
Packard Bell	2138	1314
Pael	2140	0061, 0328, 0656, 0671, 0787, 0347, 0364, 0802, 0794
Palladium	2145	0037, 0556, 0020, 0138, 0061, 0330, 0741, 0224, 0701, 0666, 0346, 0795, 0788, 0845, 0404, 0357, 0419, 0359, 0798, 0426, 0800, 0430, 0459, 1982
Palsonic	2147	0037, 0698, 0773, 1507, 0330, 0138, 0788, 0346, 0795, 0798, 0357, 0405, 0417, 1326
Panache	4069	1585
Panama	2149	0037, 0692, 0138, 0061, 0699, 0060, 0328, 0330, 0666, 0386, 0346, 0347, 0357, 0787, 0788, 0000, 0404, 0794, 0798, 0395, 0405
Panasonic	2153	0650, 1650, 0037, 1153, 0108, 0208, 0226, 0508, 0896, 1271, 1457, 1480, 1636, 0026, 0033, 0072, 0129, 0119, 0091, 0107, 0118, 0223, 0790, 0137, 0146, 0204, 0284, 0312, 0346, 0451, 0493, 0138, 0734, 0755, 0760, 0798, 0989, 1140, 1001, 1310, 0402, 0399, 0556, 0452, 0548, 0007, 0008, 0040, 0393

Panavision	2154	0037, 0138, 0346, 0357, 0798, 0367, 0426
Panda	2155	0208, 0226, 0508, 0698, 0706, 0821, 0891, 0374, 0376, 0460, 0805, 0833, 0860, 0377, 0804, 0692, 0835, 0839, 0395, 0402, 0405, 0417, 0445
PARK	3951	2104
Pathe Cinema	2168	0741, 0657, 0061, 0751, 0328, 0787, 0101, 0845, 0794, 0802, 0347, 0416, 0419, 0844, 0364, 0218
Pathe Marconi	2169	0185, 0726, 0104, 0727, 0759, 0400
Pausa	2171	0699, 0386, 0060, 0658, 0395
Peng Sheng	2181	0891
Penney	2182	0156, 0178
Pensonic	3778	0891, 0860
Perdio	2185	0037, 0328, 0138, 0346, 0693, 0787, 0357, 0367, 0416, 0293, 0798
Perfekt	2186	0037, 0138, 0346, 0357, 0798
Pershin	2188	0657, 0671
Petters	2189	0037, 1523
Philco	2192	0037, 0171, 0178, 0463, 1271, 1394, 1661, 0138, 0033, 0056, 0090, 0099, 0089, 0648, 0044, 0741, 0224, 0101, 0346, 0691, 0666, 0725, 0795, 0357, 0367, 0750, 0798, 0397
Philharmonic	2194	0061, 0330, 0000, 0788, 0404
Philips	2195	0605, 1506, 1015, 0000, 0037, 0108, 1100, 0178, 1076, 0512, 0556, 0639, 0690, 1454, 1744, 1756, 1866, 1172, 0017, 0138, 0033, 0003, 0056, 0061, 0065, 0086, 0090, 0006, 0213, 1123, 0011, 0066, 0073, 0101, 0107, 0182, 0724, 0092, 0112, 0697, 0128, 0139, 0144, 0147, 0154, 0159, 0356, 0170, 0177, 0446, 0181, 0183, 0683, 0205, 0275, 0390, 0344, 0346, 0357, 0367, 0645, 0684, 0648, 0651, 0685, 0691, 0725, 0730, 0744, 0760, 0784, 0792, 0797, 0798, 0857, 0863, 1165, 1133, 1148, 1187, 1185, 0919, 1124, 1038, 1177, 1188, 0967, 1129, 1109, 1110, 1023, 0940, 0902, 1183, 0991, 1149, 1128, 1125, 1179, 0399, 0407, 0395, 1115, 1169, 0002, 0015, 0025, 0058, 0062, 0063, 0087, 0121, 0123, 0130, 0131, 0145, 0270, 0324, 0389, 0391
Phocus	2198	0020, 1652, 1308
Phoenix	2199	0037, 0138, 0090, 0086, 0056, 0741, 0328, 0730, 0112, 0691, 0293, 0347, 0787, 0346, 0364, 0357, 0416, 0802, 0794, 0798, 0486
Phonola	2201	0037, 0556, 0056, 0086, 0138, 0033, 0328, 0065, 0648, 0090, 0112, 0347, 0730, 0346, 0066, 0364, 0691, 0352, 0787, 0390, 0357, 0802, 0794, 0367, 0798
Phonotrend	2202	0138, 0346
Pilot	2207	0706, 0712, 0803
Pioneer	2212	0037, 0512, 0698, 1260, 1457, 1636, 0138, 0504, 0086, 0072, 0741, 0104, 0458, 0153, 0112, 0344, 0346, 0730, 0357, 0367, 0755, 0759, 0792, 0798, 1048, 1086, 0464, 0679, 0400, 0407, 0486
Pionier	2213	1556, 0798, 0357, 0486
Plantron	2219	0037, 0692, 0086, 0138, 0658, 0060, 0730, 0346, 0386, 0357, 0798, 0405, 0395
Playsonic	2224	0037, 0020, 1652, 0330, 0788, 0798, 0357, 0404, 0800, 0359, 0437
Polaroid	2230	1276, 1314, 1523, 0440, 1720, 1326
Polestar	4124	0822
Policom	2231	0400, 0397
Polyvision	4304	1144
Poppy	2236	0699, 0386, 0060, 0395
Portland	2238	1661, 0797, 0356, 1909
Powerpoint	2241	0037, 0698, 0798, 0357, 1770
Prandoni	4531	0649, 0656
Prandoni Prince	4125	0044, 0071, 0107, 0790, 0666
Prandoni-Prince	2242	0656, 0666, 0750, 0754, 0760, 0790
Praxis	2243	0824
Precision	2244	0061, 0330, 0000, 0788, 0404
Premier	2248	0891, 0395, 0405
President	2250	0860
Prima	2253	0753, 1507, 0699, 0658, 0386, 0060, 0072, 0755, 0395, 0405, 0417
PrimeView	3513	1606
Princess	3514	0773, 1326
Pringston	2259	1037
Prinz	2260	0293, 0419, 0845, 0728
Profekt	4126	0138, 0346
Profex	2269	0699, 0060, 0386, 0089, 0658, 0107, 0725, 0760, 0395
Profi	2270	0395
Profilo	2272	1556, 0138, 0113
Profitronic	2273	0037, 0086, 0138, 0730, 0346, 0357, 0798, 0367, 0667
Proline	2274	0037, 0625, 0634, 1037, 0138, 0346, 0357, 0390, 0693, 0730, 0293, 0365, 0179, 0798, 1613
Promac	3779	0860
Promax	2275	0860
Proscan	2279	1447, 2147, 2256
Proscos	2280	0156
Prosonic	2282	0037, 0668, 0020, 1314, 1507, 0138, 0061, 0129, 0741, 0328, 0330, 0112, 0797, 0356, 0787, 0788, 0113, 0794, 0347, 0346, 0798, 0801, 0800, 0361, 0357, 0359, 0367, 1865, 0453, 2001, 1324, 1770, 2106, 1709
Protech	2284	0037, 0668, 1037, 0692, 0138, 0060, 0086, 0099, 0699, 0061, 0703, 0224, 0730, 0188, 0101, 0112, 0330, 0346, 0795, 0788, 0357, 0367, 0798, 0000, 0395, 0405, 0486

Proton	2288	0178, 0395
Protron	2289	1320
ProVision	2291	0037, 0556, 0020, 0138, 0112, 0113, 0346, 0352, 0798, 0357, 0800, 0359, 0425, 1324, 1531
Pvision	2300	2001
Pye	2302	0037, 0556, 0086, 0138, 0112, 0065, 0207, 0356, 0214, 0730, 0346, 0352, 0797, 0390, 0357, 0367, 0798, 0417
Pymi	2304	0699, 0386, 0060, 0395
Qingdao	2308	0208, 0226, 0833, 0835, 0692, 0402, 0405, 0417
Quadro	4071	0753, 1326
Quandra Vision	3546	0218
Quasar	2320	0650, 0099, 0671, 0395
Quelle	2322	0037, 0195, 0512, 0668, 1037, 0692, 0138, 0705, 0085, 0061, 0099, 0000, 0086, 0200, 0648, 0096, 0166, 0244, 0101, 0107, 0248, 0257, 0658, 0330, 0112, 0113, 0396, 0656, 0697, 0666, 0704, 0332, 0730, 0388, 0170, 0661, 0671, 0344, 0346, 0357, 0845, 0367, 0404, 0027, 0788, 0796, 0760, 0419, 0711, 0707, 0789, 0816, 0792, 0798, 0397, 0417, 0400, 0405, 0395
Questa	2324	0661, 0713
Radialva	2329	0138, 0349, 0346, 0406, 0367, 0663, 0400
Radio	4128	0138, 0352
Radiola	2330	0037, 0556, 0086, 0138, 0065, 0330, 0730, 0112, 0788, 0346, 0390, 0357, 0367, 0798
Radiomarelli	2331	0037, 0056, 0099, 0090, 0790, 0138, 0666, 0691, 0346, 0357, 0367, 0798
Radionette	2332	0704, 0699, 0707
RadioShack	2333	0037, 0178, 0138, 0346, 0357, 0798, 0367
Radiotone	2334	0037, 0668, 1037, 0138, 0086, 0741, 0346, 0060, 0357, 0730, 0386, 0367, 0224, 0696, 0798, 0395, 0417, 0405
Rank	2345	0705, 0713, 0396
Rank Arena	2346	0753
RBM	2350	0705, 0085
RCA	2351	0000, 0178, 0560, 0618, 0625, 0753, 1447, 1454, 1781, 2187, 2247, 2403, 2429, 0718, 0080, 0398, 0407, 0679
Realistic	2354	0178
Recco	2358	0706
Recor	2359	0037, 0138, 0346, 0357, 0798, 0367
Rectiligne	2362	0037, 0798, 0357
Rediffusion	2364	0033, 0107, 0760, 0548
Redstar	2366	0037, 0138, 0346, 0367
Reflex	2368	0037, 0668, 1037, 0138, 0346, 0357, 0798, 0367
Relisys	2374	1523, 1298, 1585
Remotec	2377	0037, 0171
Reoc	2379	0020, 0800, 0359, 1909
Revox	2383	0037, 0138, 0086, 0741, 0730, 0112, 0346, 0798, 0357, 0367, 0450
Rex	2385	0692, 0117, 0071, 0072, 0666, 0141, 0651, 0409, 0754, 0426, 0755, 0405
RFT	2386	0037, 0293, 0090, 0741, 0056, 0751, 0357, 0230, 0365, 0691, 0281, 0696, 0798, 0405, 0486
Rhapsody	2387	0328, 0787, 0347, 0794
Rinex	2392	0773, 0405
Risheng	4129	0811
Rizhi	4130	0811
R-Line	2327	0037, 0086, 0138, 0730, 0112, 0346, 0798, 0357, 0367
Roadstar	2398	0037, 0668, 0020, 1037, 0692, 0138, 0699, 0060, 0064, 0140, 0124, 0346, 0349, 0658, 0386, 0323, 0224, 0795, 0357, 0367, 0406, 0663, 0798, 0395, 0437, 0405, 1916, 1326
Robotron	2401	0648, 0056, 0691
Rolson	2410	2098
Rowa	2416	0037, 0698, 0712, 0328, 0330, 0787, 0788, 0405, 0395
Royal	2419	0658
Royal Lux	2420	0741, 0417
RTF	3548	0648, 0056, 0691
Ruyi	2425	0835, 0838, 0839
Saba	2429	0560, 0625, 0020, 0414, 0056, 0031, 0726, 0072, 0104, 0090, 0107, 0790, 0153, 0648, 0187, 0193, 0359, 0467, 0691, 0733, 0727, 0755, 0759, 0760, 0800, 0400, 0407, 0548
Sagem	2434	0618, 0427, 0236, 0665, 0881, 0610, 1596
Saige	2435	0805, 0835, 0395
Saisho	2437	0692, 0033, 0060, 0699, 0061, 0069, 0200, 0386, 0330, 0106, 0790, 0127, 0143, 0388, 0404, 0124, 0788, 0796, 0395, 0405
Saivod	2439	0037, 0668, 0712, 1037, 1163, 1556, 0798, 0357, 1982
Salora	2443	0208, 1556, 0033, 0071, 0648, 0072, 0080, 0210, 0160, 0101, 0790, 0107, 0754, 0718, 0845, 0760, 0728, 0332, 0755, 0419, 0422, 0789, 0480, 0548, 0078
Sambers	2445	0089, 0251, 0790, 0044, 0703, 0283, 0667, 0655, 0649, 0656, 0671, 0725, 0750
Sampo	2446	0171, 0178, 0650, 1755, 0395, 0398

Samsung	2448	1173, 1115, 1150, 0037, 0156, 0178, 0208, 0226, 0556, 0618, 0650, 0702, 0812, 0821, 0348, 0138, 0060, 0016, 0692, 0018, 0293, 0086, 0699, 0061, 0019, 0160, 0200, 0741, 0251, 0093, 0112, 0455, 0326, 0327, 0157, 0169, 0170, 0314, 0378, 0280, 0328, 0330, 0288, 0658, 0332, 0730, 0386, 0346, 0347, 0647, 0364, 0357, 0693, 0365, 0367, 0404, 0000, 0783, 0787, 0788, 0789, 0794, 0798, 0799, 0802, 1101, 0395, 0398, 0405, 0402, 0022, 0048, 0120
Sandra	2454	0061, 0328, 0330, 0787, 0788, 0794, 0802, 0347, 0404, 0364
Sanjian	2455	0692, 0405, 0417
Sansui	2458	0037, 0171, 0463, 0706, 0020, 0753, 1236, 1556, 0086, 0138, 0207, 0730, 0346, 0357, 0798, 0367, 0430, 0439, 0456, 1531, 0405
Santon	2459	0395
Sanyo	2462	1117, 1116, 0108, 0156, 0208, 0508, 1037, 1142, 1276, 1507, 1667, 0138, 0741, 0061, 0122, 0751, 0200, 0293, 0713, 0101, 0328, 0330, 0076, 0103, 0096, 0648, 0080, 0658, 0386, 0060, 0190, 0191, 0347, 0704, 0364, 0346, 0388, 0282, 0647, 0693, 0365, 0369, 0404, 0661, 0680, 0707, 0716, 0718, 0725, 0723, 0777, 0787, 0788, 0796, 0794, 0802, 0803, 1208, 0417, 0395, 0399, 0486, 0405, 0469, 1585, 0078
Sanyuan	2464	0376, 0805, 0804, 0835, 0839, 0395, 0398
SBR	2492	0037, 0556, 0138, 0065, 0724, 0112, 0346, 0390, 0357, 0367, 0066, 0073, 0798
Sceptre	2498	1360, 1599
Schaub Lorenz	2500	0020, 1667, 0072, 0658, 0124, 0107, 0845, 0760, 0419, 0755, 0548, 0486, 1324, 0469, 0078
Schneider	2501	0037, 0556, 0668, 0020, 1037, 0061, 0138, 0086, 0033, 0064, 0101, 0104, 0330, 0066, 0081, 0112, 0124, 0172, 0170, 0207, 0198, 0346, 0349, 0658, 0215, 0352, 0357, 0404, 0730, 0666, 0361, 0272, 0419, 0845, 0788, 0390, 0483, 0671, 0406, 0367, 0359, 0409, 0663, 0759, 0798, 0801, 0800, 0459, 0407, 1909, 1982, 1916, 1324
Scotch	2506	0178
Scott	2508	0178, 1711, 1983
Sears	2514	0156, 0171, 0178
Seaway	2515	0634
Seelver	2520	1037
SEG	2522	0037, 0668, 1037, 1163, 0692, 0138, 0061, 0089, 0099, 0703, 0281, 0092, 0060, 0476, 0713, 0328, 0330, 0101, 0112, 0386, 0666, 0661, 0346, 0347, 0725, 0357, 0787, 0788, 0367, 0404, 0794, 0798, 0405, 0395, 1909, 0078, 0255, 0264, 0269, 0299, 0300, 0331, 0341, 0370
SEI	2524	0037, 0790, 0000, 0090, 0346, 0357, 0106, 0667, 0419, 0138, 0845, 0703, 0165, 0413, 0798
Sei-Sinudyne	2525	0037, 0056, 0648, 0138, 0703, 0072, 0691, 0649, 0357, 0367, 0735, 0711, 0790, 0755, 0798
Seitech	3433	1217, 1324
Seleco	2528	0071, 0072, 0117, 0141, 0207, 0101, 0754, 0713, 0671, 0651, 0361, 0409, 0426, 0801, 0755, 0405
Semivox	2529	0463
Semp	2530	0156
Sencora	2531	0699, 0386, 0060, 0395
Sentra	2534	0660, 0060, 0386, 0349, 0761, 0110, 0663, 0406, 0392, 0395
Serie Dorada	2538	0156, 0178
Serino	2539	0328, 0236, 0364, 0787, 0665, 0802, 0427, 0610, 0398, 0461
Seye	4131	0811
Shancha	2546	0835, 0692, 0405, 0417
Shanguangdian	4132	0843
Shanghai	2547	0208, 0226, 0374, 0376, 0805, 0460, 0804, 0692, 0835, 0839, 0841, 0395, 0402, 0405, 0417
Shanshui	4133	0122, 0372
Shaofeng	2549	0803, 0804, 0369, 0835, 0838, 0839
Sharp	2550	1193, 1393, 0650, 0653, 0818, 0012, 0041, 0043, 0033, 0184, 0790, 0713, 0277, 1041, 0774, 0661, 0413, 0645, 0677, 0716, 1004, 1169, 1171, 1056, 0945, 1028, 0398, 0395, 0461, 0417, 0009, 0148, 0161, 0163, 0206, 0318
Shen Ying	2552	0395
Shencai	2553	0803, 0805, 0692, 0376, 0369, 0395, 0405, 0417
Sheng Chai	3922	
Sheng Chia	2554	0395, 0398
ShengCai	4217	0699, 0377, 0860
Shengli	4134	0834
Shenyang	2555	0753, 0376, 0805, 0804, 0692, 0835, 0395, 0405
Sherwood	2557	0805, 0395
Shinelco	4074	2104
Shintoshi	2564	0037, 0138, 0357, 0798, 0367
Shiwaki	2567	0037, 0178, 0798, 0357, 0418
Shiwan	4532	0124
Shorai	2569	0165, 0413, 0711
Show	2570	0395, 0405
Shuyuan	4135	0805
Siam	2572	0037, 0138, 0346
Siarem	2573	0090, 0056, 0648, 0703, 0101, 0649, 0138, 0346, 0691, 0667, 0027, 0790
Siemens	2574	0037, 0195, 0138, 0346, 0357, 0367, 0103, 0697, 0671, 0116, 0257, 0716, 0798
Siera	2576	0037, 0556, 0086, 0138, 0730, 0390, 0346
Siesta	2577	0741
Silva	2591	0037, 0658, 0328, 0787, 0347, 0798, 0802, 0364, 0357
Silva Schneider	2592	0037, 1556, 0798, 0357

Silver	2594	0138, 0713, 0346, 0124, 0661, 0437
SilverCrest	2595	1037
Singer	2599	0037, 0891, 1556, 0056, 0090, 0099, 0648, 0138, 0703, 0207, 0657, 0658, 0101, 0649, 0346, 0666, 0357, 0691, 0667, 0218, 0798, 0395
Sinotec	2600	0773
Sinudyne	2601	037, 0056, 0138, 0033, 0090, 0703, 0101, 0000, 0648, 0112, 0170, 0106, 0127, 0346, 0357, 0281, 0419, 0691, 0667, 0649, 0845, 0413, 0124, 0790, 0735, 0711, 0798, 1324
Skantic	2605	0072, 0755, 0422
SKY	2610	0037, 0138, 0346, 0798, 0357, 0453, 1614, 1613, 1606, 1775
SKY Brasil	3923	0453
Skysonic	2627	0753
Skyworth	2631	0037, 0698, 0753, 0762, 0377, 0860, 0804, 0835, 0692, 0395, 0405
Sliding	2635	0453, 1324
SLX	2638	0668
S-Media	3515	1217
Soemtron	2647	1298
Sogera	2649	0416
Sogo	2650	2050
Solavox	2654	0037, 0072, 0293, 0357, 0365, 0798, 0755, 0548
Sonawa	2663	0349, 0663
Songba	2665	0395
Songbai	4322	0805
Songdian	4136	0377, 0860
SongRi	4137	0699
Soniko	2669	0037, 0798, 0357
Soniq	2670	1298
Sonitron	2671	0208, 0122, 0741, 0330, 0080, 0404, 0788, 0718
Sonneclair	2673	0037, 0798, 0357
Sonoko	2675	0037, 0138, 0060, 0086, 0699, 0061, 0151, 0124, 0658, 0730, 0692, 0112, 0386, 0330, 0346, 0357, 0367, 0788, 0404, 0411, 0798, 0395, 0405
Sonolor	2676	0208, 0072, 0122, 0218, 0755, 0548
Sontec	2677	0037, 0138, 0086, 0741, 0730, 0112, 0346, 0798, 0357, 0367, 0413,
Sontech	3435	1983
Sony	2679	1651, 1505, 0000, 0650, 1087, 0927, 0810, 1825, 0010, 0013, 0699, 0033, 0713, 0200, 0244, 0313, 0142, 0209, 0357, 0388, 0661, 0667, 0485, 0673, 0675, 0693, 0716, 0796, 0798, 0859, 0921, 1050, 0987, 0653, 0397, 0037, 0556, 0398, 0001, 0004, 0051, 0189, 0196, 0240, 0243, 0249, 0310
Sound & Vision	2680	0064, 0663, 0703, 0356, 0797, 0349, 0124, 0667, 0406
Soundesign	2684	0178
Soundmaster	2685	0124, 0658
Soundwave	2689	0037, 1037, 0086, 0138, 0112, 0730, 0224, 0346, 0357, 0416, 0798, 0367, 0795, 0437
Sova	2690	1320
Sowa	2691	0156, 0178, 0226, 0402
Soyea	2692	0773
Soyo	2693	1709
Spectra	2697	0395
Squareview	2703	0171
Srypton	4138	0798, 0357
Ssangyong	2706	0395
Stag	2711	0124
Staksonic	2712	0395
Standard	2713	0037, 1037, 0061, 0699, 0060, 0086, 0138, 0064, 0124, 0658, 0330, 0730, 0386, 0346, 0356, 0349, 0663, 0357, 0367, 0797, 0404, 0788, 0000, 0416, 0406, 0798, 0395
Starlite	2728	0037, 0658, 0112, 0060, 0386, 0346, 0138, 0357, 0798, 0395, 0405, 0417
Starlux	4533	0658
Stenway	2739	0095, 0151, 0349, 0663, 0411, 0406, 0757
Stern	2741	0071, 0072, 0117, 0754, 0141, 0409, 0651, 0755, 0405
Stevison	2742	1982
Strato	2745	0037, 0138, 0060, 0346, 0386, 0357, 0367, 0798, 0405, 0395
Strong	2748	1163
Stylandia	2752	0330, 0788
Sunkai	2762	0699, 0138, 0346, 0349, 0127, 0406, 0162, 0165, 0413, 0427, 0179, 0236, 0201, 0663, 0711, 0610
Sunny	2764	0037
Sunstar	2768	0037, 0207, 0060, 0138, 0346, 0386, 0357, 0361, 0801, 0798, 0367, 0395, 0405
Sunstech	2769	2001
Sunwood	2772	0037, 0699, 0086, 0138, 0060, 0730, 0346, 0386, 0357, 0367, 0798, 0395

Superla	2782	0061, 0328, 0330, 0787, 0788, 0790, 0794, 0347
Superscan	2786	0864, 0398
Supersonic	2787	0208, 0395, 0405
SuperTech	2789	0037, 0556, 0328, 0138, 0658, 0347, 0060, 0349, 0346, 0386, 0352, 0787, 0364, 0357, 0802, 0663, 0794, 0367, 0798, 0395
Supervision	2791	0138, 0352, 0405
Supra	2792	0178, 0699, 0386, 0658, 0060, 0395
Supratech	2793	2206
Supreme	2795	0000
Susumu	2797	0064, 0187, 0124
Sutron	2798	0699, 0386, 0060, 0395
SVA	2800	0799, 0405
Svasa	2801	0208, 0405
Sven	3886	0852
Swedx	2803	1606
Swisstec	2806	1776, 2104, 1613, 1614, 1606, 0453, 1775, 0470
SWP	2807	0658
Sydney	2808	0061, 0328, 0330, 0000, 0787, 0788, 0347, 0404, 0794
Sylvania	2809	0171, 1271, 1314, 1394, 1864, 0442
Symphonic	2810	0171, 0442
Synco	2811	0000, 0178, 1755, 0398
Sysline	2815	0037, 0138, 0112, 0798, 0357, 0367
Sytong	2820	0328, 0787, 0347, 0802, 0364, 0794
T+A	2821	0447
Tacico	2823	0178, 0395
Tactus	2825	0710
Tai Wah	4139	0017
Tai Yi	2833	0395
Taishan	2835	0376, 0805, 0804, 0807, 0835, 0395
Talent	2838	0178
Tandberg	2842	0166, 0654, 0188, 0426, 0711, 0400
Tandy	2843	0061, 0012, 0064, 0072, 0330, 0657, 0293, 0102, 0666, 0124, 0693, 0663, 0349, 0365, 0404, 0788, 0406, 0758, 0000, 0755, 0398
Tantec	2845	0710
Targa	2847	0882
Tashiko	2850	0650, 0061, 0073, 0071, 0661, 0328, 0330, 0713, 0724, 0754, 0787, 0788, 0000, 0347, 0357, 0364, 0794, 0404, 0802, 0798
Tatung	2852	0037, 0156, 1556, 1756, 0061, 0138, 0086, 0710, 0293, 0134, 0330, 0140, 0112, 0730, 0170, 0693, 0647, 0346, 0352, 0788, 0388, 0796, 0359, 0790, 0365, 0367, 0000, 0404, 0800, 1720, 0395, 1324
TCL	2856	0698, 0706, 2403, 2429, 0762, 1916, 0417
TCM	2857	0020, 0119, 0699, 0138, 0342, 0692, 0207, 0113, 0866, 0867, 0450, 2001, 1308
Teac	2860	0037, 0171, 0178, 0512, 0668, 0698, 0706, 0712, 0020, 1037, 1363, 1523, 1755, 0330, 0138, 0346, 0248, 0788, 0357, 0367, 0236, 0798, 0427, 0395, 0405, 0417, 1909, 1770, 1709, 2032
Teachimagen	4140	0138, 0352
Tec	2861	061, 0699, 0099, 0658, 0187, 0060, 0666, 0101, 0386, 0330, 0102, 0188, 0357, 0788, 0758, 0846, 0000, 0404, 0798, 0395
Tech Line	2863	0037, 0668, 1163, 0798, 0357
Techica	2865	0349, 0663
Technema	2866	0416
Technica	2868	1037, 0124, 1982
Technics	2869	0556, 0650, 0091, 0119, 0137
Technika	2870	1667, 2032, 1865, 2106, 0469, 1983, 1585
TechniSat	2873	0556, 0263, 0770, 0281, 0430, 0212
Technisson	2874	0020, 1652
Techno	4076	1585
Technol Ace	2875	0405
Technosonic	2878	0556, 0625, 1324, 0425, 0453, 1326, 1982, 2032
Technotrend	2879	1531
Technovision	4141	0826
Techvision	4307	1709, 2032, 1531
Techwood	2884	1037, 1163, 1667, 0469, 0078
Tecnimagen	2885	0556
Teco	2886	0178, 0653, 1523, 0395, 0398, 0405
Tedelex	2889	0208, 0891, 1681, 0658, 0330, 0788, 0395, 1709, 1531, 0405
Teiron	2891	0395
Tek	2892	0820, 0395

Teknant	4534	0658
Teknika	2895	0150
Tele+1	2900	0033
Televia	2901	0185, 0726, 0153, 0104, 0759, 0400, 0407
Telecor	2910	0037, 0330, 0138, 0346, 0788, 0349, 0663, 0404, 0798, 0357, 0406, 0409
Telefunken	2914	0037, 0560, 0625, 0698, 0702, 0712, 0020, 0753, 0820, 0821, 0896, 1556, 1681, 0086, 0414, 0138, 0104, 0033, 0346, 0187, 0308, 0357, 0367, 0602, 0721, 0153, 0730, 0729, 0732, 0737, 0738, 0759, 0798, 0846, 1054, 0397, 0400, 0407, 0444, 0445, 0891, 1536, 0706, 0556, 0486, 0028, 0078
Telefusion	2915	0037, 0798, 0357
Telegazi	2917	0037, 0138, 0349, 0346, 0357, 0406, 0798, 0367, 0663, 0409, 0405
Telemeister	2924	0037, 0138, 0416, 0346, 0367
Teleopta	4535	0658
Teleservice	2929	0819, 0825
Telesonic	2930	0037, 0138, 0346, 0357, 0798, 0367
Telestar	2931	0037, 0556, 0138, 0346, 0357, 0798, 0367, 0395, 0417
Teletech	2934	0037, 0668, 1037, 0699, 0138, 0099, 0060, 0092, 0112, 0386, 0666, 0346, 0357, 0367, 0188, 0798, 0395
Teleton	2935	0061, 0330, 0117, 0661, 0845, 0000, 0788, 0404, 0409, 0419
Televideon	2938	0328, 0655, 0671, 0787, 0347, 0416, 0364, 0802, 0794
Television	2939	0037, 0798, 0357
Televiso	2941	0218
Temco	2946	0413
Tempest	2948	0395, 0405
Tennessee	2952	0037, 0138, 0357, 0798, 0367
Tensai	2954	0037, 1037, 0699, 0138, 0086, 0064, 0174, 0096, 0330, 0124, 0207, 0356, 0658, 0165, 0386, 0060, 0346, 0349, 0649, 0730, 0361, 0666, 0404, 0357, 0367, 0797, 0416, 0788, 0663, 0406, 0413, 0711, 0707, 0798, 0801, 0395, 0437
Tenson	2955	0416, 0395
Tesla	3680	0037, 0556, 0020, 1037, 1652, 0437, 0459, 0610
Tesmet	3550	0730, 0086
Tevion	2962	0037, 0556, 0668, 0020, 1037, 1556, 1523, 1667, 0692, 0119, 0699, 0138, 0207, 0113, 0357, 0359, 0798, 0800, 1298, 0469, 0450, 2032, 0459, 1585
Texet	2963	0061, 0060, 0328, 0330, 0356, 0386, 0124, 0797, 0000, 0787, 0788, 0364, 0404, 0802, 0395
Texla	2964	0811, 0445
Thomson	2972	0037, 0560, 0625, 0753, 1447, 0414, 0024, 0061, 0138, 0086, 0726, 0031, 0104, 0185, 0229, 0297, 0153, 0187, 0164, 0363, 0305, 0346, 0357, 0367, 0495, 0467, 0671, 0727, 0729, 0730, 0732, 0733, 0748, 0749, 0759, 0798, 0846, 0400, 0407, 0556, 0343, 0387
Thorn	2974	0037, 0512, 0138, 0033, 0107, 0710, 0660, 0112, 0293, 0149, 0357, 0187, 0114, 0346, 0367, 0110, 0096, 0248, 0365, 0109, 0244, 0257, 0693, 0671, 0761, 0258, 0739, 0647, 0707, 0760, 0721, 0798, 0844, 0399, 0400, 0401, 0397, 0407, 0425
Thorn-Ferguson	2976	0692, 0399, 0407, 0400, 0425
Tiane	2980	0835, 0398
Tiankeban	4142	0377, 0860
Tiny Digital	2987	0432
TMK	2994	0178
TML	2995	1756
Tobo	2999	0658, 0377, 0805, 0692, 0860, 0395, 0405, 0417
Tokai	3001	0037, 0668, 1037, 0086, 0138, 0658, 0330, 0356, 0730, 0346, 0188, 0693, 0357, 0797, 0788, 0367, 0404, 0293, 0798, 0395
Tokaido	3002	1037
Tokyo	3004	0061, 0328, 0660, 0787, 0347, 0794, 0392
Tomashi	3006	0095, 0151, 0349, 0411, 0663, 0757
Tongguang	3008	0692, 0405, 0417
Tongtel	3010	0445
Top Show	3681	0395, 0405
Topline	3016	0668, 1037
Toshiba	3021	1031, 0508, 0156, 0195, 0618, 0650, 0821, 1037, 1524, 0020, 0705, 0202, 0085, 0660, 0713, 0140, 0258, 0110, 0238, 0228, 0330, 0132, 0396, 0152, 0348, 0359, 0317, 0315, 0661, 0369, 0667, 0392, 0499, 0613, 0468, 0624, 0626, 0637, 0676, 0682, 0688, 0761, 0788, 0800, 0803, 1168, 1145, 1040, 1020, 0942, 0398, 0395, 0405, 0417, 0400, 1457, 1916, 0698, 0037, 1556, 0005, 0067, 0078, 0211
Tosumi	3023	1982, 1770
Towada	3028	0072, 0667, 0330, 0845, 0788, 0101, 0755, 0419
Toyoda	3030	0207, 0395, 0405
Trakton	3036	0330, 0788, 0395, 0405
Trans Continens	3037	0330, 0138, 0788, 0346, 0798, 0404, 0357
TRANS-continents	3039	0037, 0556, 0668, 1037, 0486
Transfec	4143	0347, 0794
Transonic	3041	1115, 0037, 0512, 0698, 0712, 1363, 0798, 0357, 0799, 0405, 0395, 1326
Transtec	3042	0328, 0787
Trevi	3682	0124, 0658
Triad	3049	0556, 0395
Trident	3054	0330, 0000, 0788, 0790, 0404

Tristar	3057	0349, 0663, 0406, 0405
Triumph	3058	0037, 0556, 0790, 0106, 0346, 0138, 0132
Tuntex	3069	0395
TVS	3081	0463
TVTEXT 95	3082	0556
Uher	3089	0037, 0138, 0044, 0072, 0086, 0741, 0648, 0172, 0117, 0356, 0346, 0224, 0730, 0795, 0725, 0671, 0416, 0797, 0357, 0367, 0651, 0750, 0409, 0755, 0798, 0486, 0480
Ultra	3093	0114
Ultravox	3095	0037, 0056, 0061, 0648, 0138, 0099, 0703, 0666, 0328, 0101, 0691, 0102, 0667, 0346, 0787, 0758, 0347, 0357, 0364, 0794, 0802, 0798, 0367
UMC	3099	1147, 1137, 1138, 1606, 1775, 1614, 2106, 0068, 0075, 0077
Unic Line	3100	0037, 0138, 0346, 0847, 0429, 0357, 0798, 0367, 0421
Union	3781	0246, 0258
United	3106	0037, 0556, 0020, 1037, 1652, 0138, 0092, 0112, 0798, 0357, 0800, 0359, 0367, 1983, 0437, 1916, 1982, 1770
Universal	3113	0037, 0020, 0798, 0357
Universum	3115	0037, 0195, 0512, 0618, 0668, 1037, 1163, 0138, 0044, 0692, 0086, 0099, 0098, 0741, 0096, 0101, 0112, 0330, 0224, 0681, 0332, 0658, 0396, 0227, 0248, 0346, 0352, 0388, 0257, 0730, 0664, 0704, 0666, 0357, 0367, 0845, 0795, 0847, 0404, 0671, 0661, 0188, 0419, 0027, 0796, 0788, 0429, 0413, 0707, 0426, 0750, 0789, 0798, 0397, 0405, 0480, 0421, 0400, 0395
Univox	3116	0037, 0138, 0346, 0357, 0844, 0367, 0798, 0188
Urania	4536	0658, 0671
V7 Videoseven	3130	0453, 1217, 1666
VANGUARD	3450	0658
Vegavox	4145	0224
Venturer	3143	1146, 1865
Venus	4308	1326
Vestel	3148	0037, 0668, 1037, 1163, 1667, 0071, 0072, 0086, 0099, 0730, 0138, 0754, 0101, 0330, 0788, 0741, 0112, 0113, 0755, 0798, 0346, 0352, 0357, 0404, 0367, 1585, 0469
Vexa	3149	0037, 0699, 0124, 0658, 0112, 0386, 0060, 0346, 0138, 0357, 0798, 0395
Vibrant	3154	0710
Victor	3155	0650, 0653, 0713, 0086, 0730, 0119, 0091
Videocon	3163	0037, 0508, 1540, 0853, 0395
Videologic	3165	0328, 0124, 0787, 0364, 0802
Videologique	3166	0061, 0663, 0328, 0330, 0064, 0787, 0788, 0124, 0347, 0349, 0404, 0794, 0406
Videosat	3170	0099
VideoSystem	3172	0037, 0086, 0730, 0138, 0346, 0798, 0357
Videotechnic	3173	0328, 0330, 0787, 0788, 0347, 0404, 0416, 0794
Videoton	3174	0422
Vidion	4498	0658
Vidtech	3179	0178
Viewsonic	3186	0864, 0885, 1627, 1742, 1755, 0241, 0385, 0491, 2111
Viore	3192	2352, 2104
Visa	3194	0031
Visiola	3197	0061, 0328, 0787, 0794, 0347
Vision	3198	0037, 0086, 0730, 0138, 0330, 0788, 0346, 0798, 0416, 0357, 0405
Visorex	3206	0756
Vistar	3207	0758, 0102
Vistron	3773	1363
Visual Innovations	4773	2106
Vito	4310	1852
Vivax	3601	1326, 1308, 1709
Vivo	4353	2032
Vizio	3211	0864, 0885, 1756, 1758
Vortec	3217	0037, 0086, 0730, 0138, 0112, 0798, 0346, 0357
Voxson	3220	0037, 0178, 0090, 0044, 0648, 0056, 0224, 0086, 0071, 0072, 0656, 0730, 0138, 0691, 0671, 0725, 0346, 0795, 0750, 0754, 0755
VU	4078	2098
Vue	3225	1236
Walker	4311	1667, 0469
Waltham	3230	0037, 0668, 1037, 0061, 0138, 0330, 0102, 0224, 0758, 0788, 0346, 0000, 0357, 0367, 0404, 0422, 0798, 0795, 0400, 0418
Wards	3231	0000, 0156, 0178
Warumaia	3232	0837
Watson	3233	0037, 0668, 0020, 1037, 0086, 0138, 0112, 0730, 0349, 0346, 0663, 0352, 0416, 0406, 0798, 0357, 0367, 0395
Watt Radio	3234	061, 0703, 0283, 0328, 0101, 0649, 0667, 0787, 0845, 0347, 0364, 0794, 0419, 0802, 0486
Waycon	3237	0156
Wega	3238	0037, 0056, 0090, 0138, 0713, 0346, 0691, 0357, 0367, 0661, 0798
Wega Color	4146	0815
Wegavox	3239	0386, 0658, 0060, 0395
Weipai	3241	0805, 0395
Welltech	3244	0020, 1652
Weltblick	3245	0086, 0730, 0138, 0112, 0330, 0788, 0346, 0416

Weltstar	3247	1037
Westinghouse	3249	0885, 1577, 1712, 1755
Weston	3251	0101
Wharfedale	3255	0037, 0556, 0860, 0891, 0896, 1556, 1667, 1681, 0138, 0357, 0798, 1613, 1324, 0469, 1983
White Westinghouse	3258	0037, 0463, 1661, 0061, 0138, 0328, 0703, 0112, 0725, 0347, 0787, 0188, 0346, 0364, 0802, 0416, 0794, 0352, 0357, 0798, 0367, 1909
Wilson	3260	0556
Winco	3263	0417
Windsor	3265	0668, 1037
Windstar	3266	0411, 0151
Windy Sam	3267	0556
Winston	4537	0124, 0658
Wintel	3271	0020
Winternitz	4538	0658
World-of-Vision	3282	0453, 1298, 1606, 1217
Woxter	3286	1531
Wyse	3288	1365
Xenius	3297	0634
Xiahua	3299	0698, 0773, 0376, 0805, 0804, 0692, 0835, 0395, 0405, 0417
Xianghai	3300	0395
Xiangyang	3301	0692, 0405, 0417
Xiangyu	3302	0805, 0806, 0376, 0395
Xihu	3303	0804, 0805, 0807, 0835, 0839, 0692, 0405, 0417
Xinaghai	3304	0805, 0692, 0417
Xingfu	3305	0805, 0376, 0395
Xinghai	3306	0805, 0376, 0405
Xingmenban	4147	0814
Xingyu	3926	0395
Xinrisong	3308	0377, 0860
Xinsida	3309	0841
Xiron	4079	1983
XLogic	3310	0698, 0860
Xomax	3905	1770
Xoro	3315	1507, 1217, 1324
Xrypton	3317	0037, 0138, 0346, 0367
Xuelian	3320	0374, 0460, 0839
Yakumo	3324	1613
Yamaha	3326	0650, 1576, 0682, 0689
Yamishi	3328	0037, 0330, 0151, 0346, 0349, 0138, 0788, 0404, 0236, 0357, 0411, 0406, 0663, 0798, 0427
Yingge	3334	0699, 0805, 0839, 0395
Yokan	3335	0037, 0138, 0346, 0367
Yoko	3336	0037, 0138, 0692, 0741, 0061, 0086, 0699, 0658, 0060, 0064, 0730, 0112, 0328, 0330, 0663, 0124, 0386, 0346, 0349, 0787, 0788, 0347, 0000, 0404, 0367, 0794, 0406, 0405, 0395
Yonggu	3339	0805, 0839, 0395
Yorx	3340	0064, 0658, 0349, 0406, 0663, 0124
Youlanasi	3342	0835, 0839
Yousida	3343	0805, 0395
Ytaiwai	3344	1531
Yuhang	3345	0805, 0376, 0395
YU-MA-TU	3603	0037
Yüsmart	4777	1613
Zanussi	3349	0071, 0330, 0754, 0788, 0117, 0404
Zenith	3356	0000, 0037, 0178, 0463, 1423, 1661, 0819, 1909
Zepto	4081	1585
ZhuHai	3364	0805, 0376, 0395
Ziggo	4007	1818
Zinwell	3365	1175
Zonda	3369	0698